



Libero® SoC v2021.1

SmartPower User Guide

Introduction

SmartPower is a power-analysis tool that allows you to visualize power consumption and potential power consumption problems globally and in-depth within your design, so you can make adjustments – when possible – to reduce power.

SmartPower provides a detailed and accurate way to analyze designs for Microchip SoC FPGAs, from top-level summaries to deep-down specific functions within the design, such as gates, nets, I/Os, memories, clock domains, blocks, and power supply rails.

You can analyze the hierarchy of block instances and specific instances within a hierarchy, and each can be organized in various ways to show the respective power consumption of the component pieces.

SmartPower also analyzes power by functional modes, such as Active, Flash*Freeze, Shutdown, Sleep, or Static, depending on the specific FPGA family used. You can also create custom modes that may have been created in the design. Custom modes can also be used for testing "what if" potential operating modes.

SmartPower has a unique feature that allows you to create test scenario profiles. A profile enables you to create sets of operational modes, so you can understand the average power consumed by this combination of functional modes. An example may be a combination of Active, Sleep, and Static modes — as would be used over time in an actual application.

SmartPower generates detailed hierarchical reports of the power consumption of a design for easy evaluation. This enables you to locate the power consumption source and take appropriate action to reduce the power if possible.

SmartPower supports use of files in the Value-Change Dump (VCD) format, as specified in the IEEE® 1364 standard, generated by the simulation runs. Support for this format lets you generate switching activity information from ModelSim or other simulators, and then use the switching activity-over-time results to evaluate average and peak power consumption for your design.

SmartPower supports SmartFusion®2, IGLOO®2, RTG4™, PolarFire®, and PolarFire® SoC devices.

Table of Contents

Introduction.....	1
1. Starting SmartPower.....	4
2. SmartPower Interface.....	6
2.1. Summary Tab.....	6
2.2. Domains Tab.....	8
2.3. Analysis Tab.....	11
2.4. Frequencies Tab.....	13
2.5. Probabilities Tab.....	14
2.6. Preferences Toolbar.....	15
2.7. Modes and Scenarios Toolbar.....	16
2.8. SmartPower Standard Toolbar and Menu Commands.....	17
2.9. File Menu.....	17
2.10. Edit Menu.....	18
2.11. View Menu.....	18
2.12. Tools Menu.....	19
2.13. Simulation Menu.....	19
2.14. Help Menu.....	19
2.15. Power-Settings Summary.....	19
2.16. Initializing Frequencies and Probabilities.....	20
2.17. Operating Conditions.....	26
2.18. Scenarios.....	32
2.19. Power Reports.....	35
2.20. Scenario Power Report.....	42
2.21. Activity and Hazards Reports.....	47
2.22. Export Report for Microchip Power Estimator (MPE).....	51
2.23. Freeze/Unfreeze Calculations.....	52
2.24. Importing a VCD File.....	53
2.25. Removing a VCD File.....	56
2.26. Auditing Files.....	57
3. Power Options.....	58
4. Calculating Power.....	59
4.1. Calculating Power.....	59
4.2. Extracting Power Consumption of a Specific Clock Domain.....	59
4.3. Advanced Analysis of I/Os.....	59
4.4. Adding a New Clock Domain.....	59
4.5. Verifying Lists of Clock and Data Pins of a Clock Domain.....	60
4.6. Adding a New Set of Pins.....	60
4.7. Specifying Clock and Data Frequencies in SmartPower.....	61
4.8. Verifying the InputSet.....	61
4.9. Splitting the InputSet	61
4.10. Specifying Individual Pin Frequencies.....	62
4.11. Changing the Frequency Annotation of a Pin.....	62
4.12. Removing the Frequency Annotation of a Pin.....	62

4.13. Specifying Individual Pin Probabilities.....	62
4.14. Vectorless Estimation.....	63
4.15. Viewing Results (Design Level).....	63
4.16. Analyzing Results.....	63
4.17. SmartPower Calculation Equations.....	64
4.18. Sample Equations:.....	65
4.19. Data Change History - SmartPower.....	65
5. SmartPower Tcl Commands.....	66
6. Revision History.....	67
7. Microchip FPGA Technical Support.....	68
7.1. Customer Service.....	68
7.2. Customer Technical Support.....	68
7.3. Website.....	68
7.4. Outside the U.S.....	68
The Microchip Website.....	69
Product Change Notification Service.....	69
Customer Support.....	69
Microchip Devices Code Protection Feature.....	69
Legal Notice.....	70
Trademarks.....	70
Quality Management System.....	71
Worldwide Sales and Service.....	72

1. Starting SmartPower

Set the target clock and data frequencies before you evaluate your power consumption.

1. Open the Design Flow window.
2. In the Design Flow window, right-click **Verify Power** and choose **Open Interactively**.

The SmartPower analysis tool window appears.

Figure 1-1. SmartPower User Interface (SmartFusion®2, IGLOO®2, and RTG4™)





Figure 1-2. SmartPower User Interface (PolarFire®)



2. SmartPower Interface


The following sections describe the SmartPower tabs, toolbars, and menu commands.

2.1 Summary Tab

The **Summary** tab is organized into the following sections:

- **Power Consumption**
- **Breakdown**
- **Annotation Coverage**
- **Operating Conditions**
- **Battery**

Figure 2-1. SmartPower Summary Tab



2.1.1 Power Consumption

Displays the total power consumption and the static and dynamic power of the design. The information displayed is accurate after you enter your target clock and data frequencies.

2.1.2 Breakdown

Displays a breakdown of power consumption in the design. A drop-down list allows you to view the power breakdown by type of component, voltage rail, or clock domain.

2.1.2.1 Show

Displays power usage as a chart or as a grid.

When you select **By Type** from the drop-down list, the **Summary** tab displays a breakdown of the design's power usage by the following types:

- Net
- Gate
- I/O
- Memory
- Core Static
- Banks Static
- Analog (for Fusion Designs)

Any static power used by instances of a component in a design will be included in the appropriate category. As a result, the sum of the power in breakdown by type will be equal to the total static and dynamic power consumption of the design. Percentages displayed are fractions of the total power. Global nets are included in the net power types. To obtain the power of a clock, select breakdown by clock domain.

When you select **By Rail** from the drop-down list, the **Summary** tab displays a breakdown of the power usage by the rail that the power is drawn from and a breakdown for the current usage. The power, voltage, and current drawn for each rail are displayed.

When you select **By Clock Domain** from the drop-down list, the **Summary** tab displays a breakdown of the power usage by the clock domain that the power is drawn from. For each clock domain, the power and percentage of power drawn are displayed. Dynamic power is accounted for in breakdown by clock, but static power is not associated with any clock.

By Mode is available only when a [scenario](#) is selected. When you select **By Mode** in the Modes and Scenarios toolbar, the **Summary** tab shows power consumption, duration, and power duration weight by mode.

After you select **By Type**, **By Rail**, **By Mode**, or **By Clock Domain**, you can customize the columns in the grid by right-clicking the column headers. To exclude a column, remove its check mark from the right-click menu. Right-click a column header to set the column default size for the selected column or for all columns, and then sort the values in ascending order, descending order, or customize the columns.

To sort the contents of a column, double-click a column header.

To export the contents of the grid to a file, from the **File** menu, choose **Export Grid** or click its associated toolbar button.

To print the grid, from the **File** menu, choose **Print Grid** or click its associated toolbar button. To copy the grid, from the **Edit** menu, choose **Copy Grid** or click its toolbar button.

To copy the chart, click the contents of the chart, and from the right-click menu, choose **Copy Chart to Clipboard**.

To export the chart, click the contents of the chart, and from the right-click menu, choose **Export Chart to File**.

To rotate the chart by 90 degrees, click the contents of the chart, and from the right-click menu, choose **Rotate Chart Clockwise** or **Rotate Chart Counter-Clockwise**.

2.1.3 Annotation Coverage

Displays the number and percentage of pins annotated by each source (VCD, manual annotation, SmartTime constraint, vectorless estimation, and fixed values) for all clocks, register outputs, combinational outputs, set/reset nets, primary inputs, enable pins, and other pins.

- **Hide annotation coverage** link: hides the annotation coverage.
- **Show annotation coverage** link: shows the annotation coverage.
- **Annotation Coverage Summary** drop-down menu: shows probability or frequency annotation statistics (frequency=0 shows statistics for pins that have a frequency of 0).

- **VCD:** shows the number/percentage of pins with frequencies/probabilities imported from a VCD file.
- **Manual annotation:** shows the percentage of pins with manually annotated frequencies/probabilities.
- **SmartTime constraint:** shows the percentage of pins initialized with SmartTime.
- **Fixed values:** shows the percentage of pins with default frequency/probability.
- **Vectorless estimation:** shows the percentage of pins that have been annotated with vectorless estimation.

2.1.4 Operating Conditions

Displays the temperature and voltage operating conditions for the selected mode or scenario specified in the [Operating Conditions dialog box](#). When you select a scenario, the temperature and voltage operating conditions for each mode in the scenario are displayed.

To change the operating conditions, click the **Change Operating Conditions** link or from the **Tools** menu, and then choose **Operating Conditions**.

2.1.4.1 Battery

Allows you to set the battery capacity in mA/hr and reports the battery life.

2.2 Domains Tab


The **Domains** tab lists existing domains along with their corresponding clock and data frequencies and probability data for clock domains and sets of pins. In this tab, you can add, edit, or remove domains or sets of pins, and change the clock and/or data frequency for a selected domain.

When you start SmartPower for the first time, it automatically initializes frequencies from SmartTime with a default data toggle rate of 10%. However, if you update your timing constraints in SmartTime, you can use the [Initialize Frequencies and Probabilities](#) dialog box to update SmartPower with new frequencies from SmartTime. If you do not have timing constraints in SmartTime, you can initialize clock and data frequencies manually by directly editing the **Domains** tab grid or using the Initialize Frequencies and Probabilities dialog box.

If you import a VCD file, the **Domains** tab shows the average clock and data frequencies for each clock domain and input set. This average is calculated using VCD information.

Note: If you change a clock or data frequency in the **Domains** tab, it impacts only nets that use the default estimation source. Nets use the default estimation source when they have not been manually set to a specific frequency in the **Frequencies** tab, and when they have not been set by importing a VCD file. To see explicitly the list of nets using the default estimation source, refer to the [Frequencies tab](#).

Figure 2-2. SmartPower Domains Tab



Summary Domains Analysis Frequencies Probabilities

Show: ☒ Frequencies ☐ Probabilities

Clock domains

	Status	Name	Clocks (MHz)	Register outputs	Set/Reset nets	Primary inputs (MHz)	Combinational outputs (MHz)
1		CLKIN	100	5 (10 %)	0 (0 %)	5 (10 %)	5 (10 %)

Hide set of pins

Set of pins

	Status	Name	Data (MHz)
1		Input to Output	0

Frequencies and Probabilities displayed in this tab are default values. They are used for nets that have not been annotated by any method (i.e. VCD or manual annotation). Changing these values may not impact power estimation, depending on the percentage of nets annotated.

Note: Data and clock frequencies are set to zero automatically when in non-active modes.

To hide or display the grid for set of pins, click the **Hide/Show set of pins** link. You can edit frequency or probability data directly from the grid.

To create a new clock domain or set of pins:

1. Right-click the clock domain or set of pins and choose **create new clock domain** or **create new set of pins**.
2. Enter a name and click **OK**. The new clock domain or set of pins appears in the **Domains** tab.
3. Modify the frequency and probability data as needed.

To initialize, clock domain frequencies, right-click the clock domain name and select **Initialize Frequencies and Probabilities**. If there is no frequency constraint set for the clock domain in SmartTime, the clock frequency of the domain is not changed.

The status of a clock frequency or probability is displayed in the first column by an icon. Mouse over the icon to identify the status (see the following table).




Table 2-1. Clock Frequency/Probability Status

Icon	Description
	This clock has not been initialized.
	No constraints available for this clock from SmartTime.
	Average frequencies/probabilities imported from VCD.
	Clock constraints imported from SmartTime.
	This clock has been initialized manually.

Note: The frequency and probability distribution feature is available only in active operating mode or when in a mode based on the Active mode.

An icon in the first column shows the status of a set of pins. Mouse over the icon to identify the status (see the following table).

Table 2-2. Set of Pins Status

Icon	Description
	This set has not been initialized.
	Average frequencies/probabilities imported from VCD.
	This set has been manually initialized


Note: The frequency and probability distribution feature is available only in active operating mode or when in a mode based on the Active mode.

To remove one or multiple clock domains, select the clock domain(s) and click **Remove Selected Domains(s)**.

To edit a clock domain or a set of pins:

1. Select the clock domain and from the right-click menu, and choose **Edit Domain**. The Clock Domain or Set-of-Pins window appears.

Figure 2-3. Clock Domain Window



Any pins that do not belong to a domain appear under **Unclassified Pins**. You can select a pin from this list and add it to the current domain. You can also select a pin from the current domain and remove it from the domain (this pin will appear under **Unclassified Pins**).

Clock Pins and Data Pins: Select **Clock Pins** from the pull-down list to display all clock pins for the selected domain, or select **Data Pins** to display registers, asynchronous signals, primary input, and combinational signals for the selected domain.

Use the **filter** boxes to narrow your search for a specific pin. The boxes are text filters; * is a wildcard.

2. Click **OK**.


To delete a clock domain or a set-of-pins, select the clock domain or set-of-pins and choose **Remove Domain** from the right-click menu.

2.3 Analysis Tab

The **Analysis** tab allows you to inspect detailed hierarchical reports of the power consumption. The **Analysis** tab consists of two windows:

- Hierarchy of Instances window
- Analysis window

Figure 2-4. SmartPower Analysis Tab



2.3.1 Hierarchy of Instances Window

SmartPower lists the hierarchy of instances in the Hierarchy of Instances window. Clicking the plus sign (+) next to a block expands the block to show its sub-blocks. Only hierarchical blocks are displayed in this list (no gates or nets).

When you select a block of the hierarchical tree, SmartPower displays its name and power consumption in the Analysis window.

2.3.2 Analysis Window

The Analysis window is organized into two sections:

- **Power Consumption**
- **Breakdown**

2.3.2.1 Power Consumption

Displays the name of the currently selected block from the hierarchy of instances window, as well as the static and dynamic power consumption of the selected block.

2.3.2.2 Breakdown

Displays a breakdown of power usage of the currently selected block. Use the drop-down list to view the power breakdown by type of component (instance, or clock domain).

When you select **By Type** from the drop-down list, the **Analysis** tab shows a breakdown of the selected block's power usage by the following types:

- Net
- Gate

- I/O
- Memory
- Core Static
- Banks Static
- Analog

Any static power used by instances of a component in a design are included in the appropriate category.

The sum of the power in breakdown by type equals the total static and dynamic power consumption of the design. Percentages displayed are fractions of the total power. Global nets are included in the net power types. To obtain the power of a clock, select breakdown by clock domain.

When you select **By Clock Domain** from the drop-down list, the **Analysis** tab shows a breakdown of the power usage by the clock domain that the power is drawn from. For each clock domain, the power and percentage of power drawn are displayed. Dynamic power is accounted for in breakdown by clock, but static power is not associated by any clock.

When you select **By Type**, **By Instance** or **By Clock Domain**, you can customize which columns are displayed in the grid by right-clicking the column headers. To exclude a column, remove its check mark from the right-click menu. Right-click a column header to set the column default size for the selected column or for all columns, and then sort the values in ascending order, descending order, or customize the columns.

To sort the contents of a column, double-click a column header.

To export the contents of the grid to a file, choose **Export Grid** from the **File** menu, or click its associated toolbar button.

To print the grid, choose **Print Grid** from the **File** menu, or click its associated toolbar button. To copy the grid, choose **Copy Grid** from the **Edit** menu or click its toolbar button.


To copy the chart, right-click the contents of the chart and choose **Copy Chart to Clipboard**.

To export the chart, right-click the contents of the chart and choose **Export Chart to File**.

To rotate the chart by 90 degrees, click the contents of the chart and choose **Rotate Chart Clockwise** or right-click **Rotate Chart Counter-Clockwise**.

To view an instance's properties, right-click any instance and choose **Instance Properties**. The Instance Properties window appears, with the instance name, type and power and other properties specific to each type of instance (see the following figure).

Figure 2-5. Instance Properties: Gate



The Instance Properties window allows you to access a list of pins of a gate, and check their domain and frequency.

For more information, see:

- [4.16 Analyzing Results](#)
- [4.3 Advanced Analysis of I/Os](#)

2.3.2.2.1 Show

Displays power usage as a chart or grid.

Note: The power usage chart is not available when **breakdown by instance** is selected.

2.4 Frequencies Tab

Use the **Frequencies** tab to attach switching frequency attributes to the interconnects of the design.

The **Frequencies** tab is organized into the following areas:

- **Switching Frequencies**
- **Average Frequencies**
- **Annotation Statistics**

Figure 2-6. Frequencies Tab

Summary Domains Analysis **Frequencies** Probabilities

Switching Frequencies:

Driver: * Set Domain: All Source: All

	Driver	Net	Domain	Frequency (MHz)	Source
1	PWM_out_pad/U0/U1:DOU	PWM_out_pad/U0/NET1	un1_dataa_int	0	Fixed Values
2	PWM_out_pad/U0/U0:PAD	PWM_out	un1_dataa_int	0	Fixed Values
3	nPWM_out_pad/U0/U1:DOU	nPWM_out_pad/U0/NET1	un1_dataa_int	0	Fixed Values
4	nPWM_out_pad/U0/U0:PAD	nPWM_out	un1_dataa_int	0	Fixed Values
5	un1_dataa_int_NE:Y	un1_dataa_int_NE	un1_dataa_int	0	Fixed Values
6	PWM_out:Q	PWM_out_c	un1_dataa_int	0	Fixed Values
7	nPWM_out:Q	nPWM_out_c	un1_dataa_int	0	Fixed Values
8	Aclr_pad/U0/U0:Y	Aclr_pad/U0/NET1	PWM_clk (set/	0	Fixed Values
9	PWM_clk	PWM_clk	PWM_clk (cloc	0	Fixed Values
10	PWM_clk_pad/U0/U0:Y	PWM_clk_pad/U0/NET1	PWM_clk (cloc	0	Fixed Values
11	PWM_data_in<5>	PWM_data_in[5]	PWM_clk (prim	0	Fixed Values
12	PWM_data_in<3>	PWM_data_in[3]	PWM_clk (prim	0	Fixed Values

Set Frequencies for selected pins Reset Frequencies for selected pins Select all

Average Frequencies:

Pin: 0 MHz

Annotation Statistics:

VCD Import: 0 %
Manual Annotation: 0 %
Fixed Values: 100 %
Vectorless Estimation: 0 %

2.4.1 Switching Frequencies

Displays the pins and lists the net, domain, frequency, and frequency source for each pin.

The **Driver** box allows you to filter the list of pins based on the criteria entered. Enter text in the filter box and click **Set** to apply this text as a filter. Use the * character to display all pins or as a wildcard.

Use the **Domain** drop-down list to select a different domain (All, CLKIN, Default, or Input to Output).

Use the **Source** drop-down list to select a different source (All, Default, Manual Annotation, or VCD Import).

To change the frequency, enter a new value in the **Frequency** column, or select multiple pins, click the **Set frequencies for selected pins** button, and enter a new frequency. Use **Reset frequencies for selected pins** to revert to the default frequency.

To select all the pins, click **Select All**.

2.4.2 Average Frequencies

Displays the average frequency of all pins displayed in the grid.

Average frequencies are useful when you import a VCD file. Because these files allow you to specify the frequency of each pin individually, it is useful to know the average clock pin or data pin frequency for a particular clock domain.

If you did not specify a frequency annotation for any clock pin in this clock domain, the average value is equal to the default clock frequency of the clock domain. If you set one or several clock pins, SmartPower takes those annotations to compute an average value.

If you did not specify a frequency annotation for any data pin in this clock domain, the average value is equal to the default data frequency of the clock domain. If you set one or several data pins, SmartPower considers these annotations into account to compute an average value.

2.4.3 Annotation Statistics

VCD import: displays the percentage of pins with frequencies imported from the *.vcd file.

Manual annotation: displays the percentage of pins with manually-annotated frequencies.

Fixed values: displays the percentage of pins with default frequency.

2.5 Probabilities Tab

The **Probabilities** tab displays the drivers, nets, types, polarity, rates, and source for each pin. Use the **Probabilities** tab to control the probabilities for all pins.

- **Bidirectional and Tristate I/Os:** controls the output probability of each tristate and bidirectional I/O. The probability is the percentage of time that the I/O is used as an output. You can change the default value and set a specific value for each bidirectional or tristate I/O.
- **Memories:** controls the read cycle probability or the write cycle probability of a memory block. The probability is the percentage of time that a memory block will be used in a read cycle or a write cycle. You can change the default value and set a specific value for each enable pin of each memory block available in the design. If an enable pin is active low, assign it a probability of 0% to completely enable the I/O or the memory block, or 100% to disable it completely.

Figure 2-7. SmartPower Probabilities Tab

	Driver	Net	Type	Polarity	Probability (%)	Source
1	rst_n	rst_n	Input to	--	99.9949	Manual A
2	rst_n_pad/U0/U0:Y	rst_n_pad/U0/NET1	Input to	--	99.9949	Manual A
3	rst_n_pad/U0/U1:Y	rst_n_c	Input to	--	99.9949	Manual A
4	fpu_op<0>	fpu_op[0]	Input to	--	0	Manual A
5	fpu_op_pad[0]/U0/U0:Y	fpu_op_pad[0]/U0/NET1	Input to	--	0	Manual A
6	fpu_op_pad[0]/U0/U1:Y	fpu_op_c[0]	Input to	--	0.000003	Manual A
7	UUT/un1_fpu_op_3_0_a2	UUT/N_1112	Input to	--	0.000003	Manual A
8	UUT/fracta_mul_w_0_a2	UUT/N_1111	Input to	--	0.000003	Manual A
9	fpu_op<1>	fpu_op[1]	Input to	--	0	Manual A
10	fpu_op_pad[1]/U0/U0:Y	fpu_op_pad[1]/U0/NET1	Input to	--	0	Manual A
11	fpu_op_pad[1]/U0/U1:Y	fpu_op_c[1]	Input to	--	0.000003	Manual A
12	UUT/un1_fpu_op_1_0_a2	UUT/N_1026	Input to	--	0.000003	Manual A
13	fpu_op<2>	fpu_op[2]	Input to	--	0	Manual A
14	fpu_op_pad[2]/U0/U0:Y	fpu_op_pad[2]/U0/NET1	Input to	--	0	Manual A
15	fpu_op_pad[2]/U0/U1:Y	fpu_op_c[2]	Input to	--	0.000003	Manual A
16	UUT/fracta_denorm[30]:Q	UUT/fracta_denorm[30]	UUT/un3_out_	--	0.0125	Manual A
17	UUT/fracta_denorm[32]:Q	UUT/fracta_denorm[32]	UUT/un3_out_	--	0.0125	Manual A
18	UUT/fracta_denorm[31]:Q	UUT/fracta_denorm[31]	UUT/un3_out_	--	0.0125	Manual A

In designs with a cascaded memory, all memory enable pins are shown in the **Probabilities** tab. To simulate real-world power consumption, selectively enable only some memory enable pins, as specified in the memory cascading structure.

- For purely vertical cascading, enable the pins that belong to one RAM block.
- For purely horizontal cascading, enable all pins belonging to all RAM blocks of the cascaded memory.

To find which RAM block corresponds to which pin, cross-probe with the MVN NetlistViewer.

The **Driver** box allows you to filter the list of drivers based on the criteria entered. Enter text in the filter box, and click **Set** to apply this text as a filter. Use the * character as a wildcard.


Use the **Type** drop-down list to filter the pin list by different type (All, All enable, CLKIN, Default, or Input to Output).

Use the **Polarity** drop-down list to filter the pin list by polarity (Low, High, or All).

Use the **Source** drop-down list to filter the pin list by source (All, Default Estimation, Manual Annotation, SDC, VCD Import).

To change the rate, enter a new value in the **Rate** column, or select multiple pins, click the **Set Probabilities for selected pins** button, and enter a new frequency in the Set Default Probabilities dialog box.

Figure 2-8. Set Probability for Pins Dialog Box



Use **Reset Probabilities for selected pins** to revert to the default polarity. You can change the default probability from the **Domains** tab.

To select all the drivers, click **Select All**.


You can set or reset the probabilities, set a default probability, copy, export, or print the grid by selecting one or multiple pins and choosing an option from the right-click menu.

For more information, see [4.13 Specifying Individual Pin Probabilities](#).

2.6 Preferences Toolbar

The SmartPower Preferences toolbar appears on the right side of the row below the menus. It provides quick access to commonly used settings. Mouse over the toolbar button to view a description of the command. Use the drop-down list to select your settings.

Figure 2-9. SmartPower Preferences Toolbar




- **Operating Conditions:** allows you to set the operating conditions: Best, Typical, or Worst. The actual voltage and temperature of a given operating condition is defined by the operating condition range selected for the current design (COM, IND, MIL, Auto, TGrade1, TGrade2, and Custom). For SmartPower, unlike SmartTime, the worst voltage is the upper bound of the range. That is, higher (worst-case) power comes from higher voltage, while higher voltage results in best-case speed.

Note: Worst-case and best-case calculations are available only for certain families and devices.

- **Frequency Preferences:** sets unit preferences for frequency: Hz, KHz, MHz.
- **Power Preferences:** sets unit preferences for power: W, mW, or uW.


2.7 Modes and Scenarios Toolbar

The Modes and Scenarios toolbar appears as the left pane in the SmartPower interface. It displays all predefined modes, custom modes, predefined scenarios, and custom scenarios.



The Modes and Scenarios toolbar is shown by default, but can be closed or undocked. To view the toolbar, choose **Modes and Scenarios toolbar** from the **View** menu.

Figure 2-10. Modes and Scenarios Toolbar



From this toolbar, you can:

- Select a predefined mode by clicking the mode name.
 - Select a **custom mode** by clicking the mode name.
 - Select a custom mode for power-driven layout by right-clicking the active-based mode and selecting **Use for PDPR**.
 - Re-import a VCD file from an Active mode or a custom mode by right-clicking the VCD file and selecting **Re-import VCD File**.
 - Remove a VCD file from an Active mode or a custom mode by right-clicking the VCD file and selecting **Remove VCD File from <mode name> Mode** or by choosing **Remove VCD File <file name>** from the **Simulation** menu.
 - Generate an Activity and Hazards Power report by right-clicking the VCD file and selecting **Activity and Hazards Power Report**.
 - Create a new custom mode by clicking **Custom modes** and selecting **New Custom Mode**, or by clicking the **New Custom Mode** hyperlink.
 - Edit and delete a custom mode by right-clicking the mode name and selecting **Edit custom mode** or **Delete custom mode**.
 - Copy a custom or predefined mode by right-clicking the mode name and selecting **Create a copy of this mode**.
 - Select a **scenario** by clicking the scenario name.
 - Create a new custom scenario by clicking **Scenarios** and selecting **New custom scenario**.
 - Edit and delete a custom scenario by right-clicking the scenario name and selecting **Edit custom scenario**.
 - Copy a scenario by right-clicking the scenario name and selecting **Create a copy of this scenario**.
- Note:** When a scenario is selected, only the **Summary** tab is available.

2.8 SmartPower Standard Toolbar and Menu Commands

The SmartPower standard toolbar contains commands for performing common SmartPower operations on your designs. Roll the mouse pointer over the toolbar button to view a description of the button. Click the button to access the command.




Table 2-3. SmartPower Toolbar

Toolbar Button	Description
	Commit
	Settings Summary
	Operating Conditions
	Options
	Export Path Grid
	Copy Path Grid
	Print Grid
	Generate Power Report
	Initialize Frequencies and Probabilities
	Refresh vectorless estimation
	Freeze/Unfreeze Calculations

The PC and UNIX workstation versions of SmartPower have the same menus. However, some dialog boxes, field locations and names, and buttons may look slightly different on the two platforms due to the different window environments.

2.9 File Menu

Menu	Description
Commit	Commits power information. You must commit your changes if you wish to save your settings in SmartPower. If you commit your changes, the information is stored in the .adb file, and your settings are restored the next time you open your design in SmartPower.
Export Grid	Exports the selected area of the Report window to a text (.txt) file.
Print Grid	Prints the selected area of the Report window.
Settings Summary	Displays a summary of the power settings for the current design.

.....continued

Menu	Description
Close	Closes SmartPower.

2.10 Edit Menu

Menu	Sub-Menu	Description
Domains	New Clock Domain	Adds a clock domain.
	New Set of Pins	Adds a set of pins.
	Delete Domain	Deletes a clock domain.
	Edit Domain	Edits a clock domain.
Modes and Scenarios	Use for Analysis > <i>mode or scenario name</i>	Sets the selected mode or scenario to be used for analysis.
	Use for PDPR > <i>mode or scenario name</i>	Sets the selected mode or scenario to be used for a power-driven layout.
	Custom Modes > New Custom Mode	Creates a new custom mode.
	Custom Modes > Edit Custom Mode	Edits a custom mode.
	Custom Modes > Delete Custom Mode	Deletes a custom mode.
	Custom Scenarios > New Scenario	Creates a new custom scenario.
	Custom Scenarios > Edit Scenario	Edits a custom scenario.
	Custom Scenarios > Delete Scenario	Deletes a custom scenario.
Copy Grid	—	Copies the selected cells of the dynamic grid onto the Clipboard.

2.11 View Menu

Menu	Description
Standard Toolbar	Displays or hides the Standard toolbar.
Preferences Toolbar	Displays or hides the Preferences toolbar .
Modes and Scenarios Toolbar	Displays or hides the Modes and Scenarios toolbar .
Unprocessed Simulation Files Toolbar	Displays or hides the Unprocessed Simulation Files toolbar.
Customize Columns	Selects and orders the columns displayed in the user interface.
Reset Window Layout	Resets the window layout to the default layout.

2.12 Tools Menu

Menu	Sub-Menu	Description
Initialize Frequencies and Probabilities	—	Imports clock constraints from SmartTime, and allows you to enter frequencies and probabilities for the design, as shown in the Initializing Frequencies and Probabilities section.
Operating Conditions	—	Allows you to customize the operating conditions used in SmartPower.
Options	—	Displays the Options dialog box, where you can set analysis and display preferences.
Reports	Power Report	Generates a power report .
	Scenario Power Report	Generates a scenario power report .
	Activity and Hazards Power Report	Generates an activity and hazards power report .
Export Report for MPE	—	Exports a report for Microchip Power Estimator (MPE) .
Freeze/Unfreeze Calculations	—	Freezes or unfreezes the computations that happen to avoid the SmartPower tool from slowing down

2.13 Simulation Menu

Menu	Description
Import VCD File	Displays the Import VCD Options dialog box.
Remove VCD file	Removes the selected VCD file from the design.
Audit files	Audits simulation files within the project.

2.14 Help Menu

Menu	Description
Help on <i>current tab</i>	Displays the help content for the current tab.
Help Topics	Opens the help files for SmartPower.
SmartPower User's Guide	Displays the SmartPower User's Guide.
Data Change History	Displays the data change history report .

For more information, see the [SmartPower Preferences Toolbar](#).

2.15 Power-Settings Summary



The Power-Settings Summary dialog box summarizes the power settings for the current design. To open the dialog box, choose **Settings Summary** from the **File** menu or click the  icon in the SmartPower toolbar.

Figure 2-11. Power-Settings Summary Dialog Box



The Power-Settings Summary dialog box shows the following information.

Table 2-4. Power-Settings Summary Dialog Box Attributes

Attribute	Description
Data Source	Displays the data source.
Design	Displays the name of the design.
Family	Displays the device family used in the design.
Die	Displays the die.
Package	Displays the package.
Temperature Range	Displays the temperature range.
Voltage Range	Displays the core supply voltage.
Operating Condition	Displays the operating conditions that SmartPower uses to calculate static and dynamic power contributions.
Operating Mode	Displays the operating mode that SmartPower uses to calculate static and dynamic power contributions.

Note: The status bar also shows the ambient temperature, VCCA, and speed grade.

2.16 Initializing Frequencies and Probabilities

The Initialize Frequencies and Probabilities dialog box allows you to initialize the frequencies and probabilities for your design.

To open the Initialize Frequencies and Probabilities dialog box, choose **Initialize Frequencies and Probabilities**

from the **Tools** menu, or click the  icon in the SmartPower toolbar.


Note: This feature is available only in the Active operating mode or in modes derived from the Active mode.

The dialog box is organized into the following panels:

- General
- Clocks
- Register Outputs
- Set/Reset Nets
- Primary
- Inputs
- Combinational Outputs
- Enables Sets of Pins
- Other Sets of Pins

2.16.1 General

Figure 2-12. Initialize Frequencies and Probabilities Dialog Box – General



Initialize mode: select an active-based mode for which you want to initialize the frequencies and probabilities.

For pins that have not been annotated, SmartPower can estimate their frequency and probability using vectorless analysis or fixed values:


- **Use vectorless analysis:** SmartPower initializes frequencies and probabilities with vectorless analysis.
- **Use fixed values:** SmartPower initializes frequencies and probabilities (%) of all registers with a default toggle rate (when using toggle rates), frequency, and probability.

Based on the selected mode, a warning appears with information about the annotated pins. If the selected mode contains annotations, you can remove them by selecting one or both of the following options:

- **Remove Simulation file (VCD) if any:** removes the simulation file for the selected mode.
- **Remove any manual annotations:** removes all manual pin annotations for the selected mode.

2.16.2 Clocks

Figure 2-13. Frequencies and Probabilities Dialog Box – Clocks




- **Initialize clock frequencies and duty cycles:** initializes clock frequencies and duty cycles with one of the following:
 - **with clock constraint if available in SmartTime:** when only this box is checked, SmartPower initializes all clock domains in SmartPower with clock constraints from SmartTime. If there is no frequency constraint set for this clock domain in SmartTime, the clock frequency of the domain will not be updated.
 - **else, with default frequency (MHz) and duty cycle (%):** when only this box is checked, SmartPower initializes all clock domains in SmartPower with the specified default frequency and duty cycle.

Note: When both boxes are checked, and **with clock constraint if available in SmartTime**, **else default frequency**, and **and duty cycle** selected, SmartPower initializes all clock domains with clock constraints from SmartTime. If there is no frequency constraint set for a clock domain in SmartTime, it is initialized with the specified default frequency and duty cycle.

2.16.3 Register Outputs

Figure 2-14. Frequencies and Probabilities Dialog Box –Registers




Initialize frequencies and probabilities: initializes frequencies and probabilities for register outputs in your design.

with Vectorless analysis: SmartPower initializes frequencies and probabilities using vectorless analysis.

with fixed values: SmartPower initializes frequencies and probabilities (%) of all register outputs with a default toggle rate (available only when using toggle rates) or frequency (when not using toggle rates), and a default probability.

2.16.4 Set/Reset Nets

Figure 2-15. Frequencies and Probabilities Dialog Box – Set/Reset nets



Initialize frequencies and probabilities: initializes frequencies and probabilities for set/reset nets in your design.


with fixed frequency (MHz): SmartPower initializes all primary inputs in SmartPower with the specified fixed frequency. This option is available only when not using toggle rates.

with fixed toggle rate (%): SmartPower initializes frequencies and probabilities of all set/reset nets with the specified fixed toggle rate. This option is available only when using toggle rates.

with fixed probability (%): SmartPower initializes probabilities of all set/reset nets with the specified fixed probability.

2.16.5 Primary Inputs

Figure 2-16. Frequencies and Probabilities Dialog Box – Primary Inputs



Initialize frequencies and probabilities: initializes frequencies and probabilities for the primary inputs in your design.


with fixed toggle rate (%): SmartPower initializes frequencies and probabilities of all primary inputs with the specified fixed toggle rate. This option is available only when using toggle rates.

with fixed frequency (MHz): SmartPower initializes all primary inputs in SmartPower with the specified default frequency. This option is available only when not using toggle rates.

with fixed probability (%): SmartPower initializes probabilities of all primary inputs with the specified fixed probability.

2.16.6 Combinational Outputs

Figure 2-17. Frequencies and Probabilities Dialog Box – Combinational Outputs




Initialize frequencies and probabilities: initializes frequencies and probabilities for the combinational outputs in your design.

with Vectorless analysis: SmartPower initializes frequencies and probabilities with vectorless analysis.

with fixed values: SmartPower initializes frequencies and probabilities (%) of all combinational outputs with a default toggle rate (available only when using toggle rates) or frequency (when not using toggle rates), and a default probability.

2.16.6.1 Enables

Figure 2-18. Frequencies and Probabilities Dialog Box – Enables




Initialize frequencies and probabilities: initializes frequencies and probabilities for the enable sets of pins in your design.

with Vectorless analysis: SmartPower initializes frequencies and probabilities with vectorless analysis.

with fixed values: SmartPower initializes frequencies and probabilities of all enables sets of pins with the specified default probability and frequency.

2.16.6.2 Others

Figure 2-19. Frequencies and Probabilities Dialog Box – Others



Initialize frequencies and probabilities: initializes frequencies and probabilities for the other sets of pins in your design with default values.

with Vectorless analysis: SmartPower initializes frequencies and probabilities with vectorless analysis as specified in the primary inputs frequency and probability.

with fixed values: SmartPower initializes frequencies and probabilities (%) of all other sets of pins with a default frequency and probability.


2.17 Operating Conditions

The SmartPower Operating Conditions dialog box allows you to customize the operating conditions used in SmartPower for voltage and temperature.

Note: Changes will apply only to SmartPower and will not change the operating conditions set in Designer.


The **General** panel allows you to select the operating condition you want to apply to SmartPower: Best, Typical, or Worst.

Figure 2-20. SmartPower Operating Conditions Dialog Box - General




The process settings panel allows you to select the process characteristic.

Figure 2-21. SmartPower Operating Conditions Dialog Box - Process Settings



You can customize temperature settings in the Temperature Settings panel, and the voltage settings in the Voltage Settings panels — each VCC voltage used in the design appears under Voltage settings.


Figure 2-22. SmartPower Operating Conditions Dialog Box - Temperature Settings



Select one of three options to specify the temperature or voltage settings:

- **Design operating range (default):** sets the temperature or voltage operating range as specified in your Project Settings.
- **Custom operating range:** sets the temperature (junction or ambient) or voltage operating range for the current design in SmartPower only. Enter temperature values in degrees Celsius and voltage values in volts for Best, Typical, and Worst.
- **Mode by mode operating range:** sets the temperature (junction or ambient) or voltage for each mode in SmartPower only. Use the grid to enter temperature values in degrees Celsius and voltage values in volts for each mode, or select multiple modes in the grid, and click the **Set values for selected modes** button to enter the same values for all selected modes.

Figure 2-23. SmartPower Operating Conditions Dialog Box - Mode-Specific Temperature Settings



The junction temperature and static power are computed iteratively until they converge. The formulas are:

$$T_J = T_A + \theta_{JA} \cdot (P_{dynamic} + P_{static})$$

$$P_{static} = f(T_J) = P_0 + P_1 \cdot T_J$$


If the computed junction temperature is outside the operating condition range (smaller than the best case value or greater than the worst case value), a violation warning will be reported.

Both T_J and P_{static} will be re-computed when any of the following parameters are changed:

- Ambient temperature
- Cooling style
- Custom thermal resistance or any parameters/options that affect the static or dynamic power values:
- Junction Temperature Display Mode
- Operating Condition (Affect dynamic power)
- Operating Mode (Affect dynamic power)
- Any of the clock domain frequencies (Affect dynamic power)

If you specified the Ambient temperature in the Temperature Settings panel, you can select the thermal characteristic for θ_{JA} .

Figure 2-24. SmartPower Operating Conditions Dialog Box - Thermal Resistance Settings



The thermal resistance is predefined for Still Air, 300 ft/min and Case Cooling. To enter a custom thermal resistance, select **Custom** from the thermal characteristic for ThetaJA.

SmartPower also reports the thermal resistance ThetaJA.

2.17.1 Custom Operating Modes

SmartPower allows you to use predefined and custom operating modes. A predefined operating mode is an inherent mode of a family of devices that comes with a number of hard availability constraints on the FPGA resources. Custom operating modes are user-defined modes based on one of the predefined modes available for the family, where parameters such as clock, data, and toggle rate frequencies have been customized. A custom mode can also be linked to a VCD.

Custom modes can be used:

- To define additional modes where the chip is in the active predefined mode, but where the clock frequencies or the toggle rates are scaled up or down.
- To import multiple VCD files that capture individual steps that take place in different modes.
- To define a sequence of modes with a duration for each mode and get an estimate of the overall power consumption, from which extrapolate the battery life for the application. The Scenario Power report allows you to define a sequence of modes and estimate the weighted average of the power consumption of the chip over the entire sequence.
- To define additional modes where the chip is in a predefined mode, but the junction/ambient temperature or the rails' voltage modes are different.

2.17.1.1 Setting the Current Mode

To set the current mode:

1. From the **Edit** menu in SmartPower, choose **Modes and Scenarios > Use for Analysis > mode name** or select the mode in the Modes and Scenarios toolbar.
Enter the result of your step here (optional).


2.17.1.2 Creating a New Custom Mode

To create a new custom mode:

1. From the **Edit** menu in SmartPower, choose **Modes and Scenarios > Custom Modes > New Custom Mode** or click **Custom Modes** in the Modes and Scenarios toolbar, and select **New custom mode**.

The New Custom Mode dialog box appears.

Figure 2-25. New Custom Mode Dialog Box




2. Enter the mode name, select the base mode, and enter comments that describe the mode. The base mode can be either a user-defined custom mode or the active mode. The new mode will inherit all clock and data frequencies and annotations of its base mode.
3. Click **OK**. The newly created operating mode is set as default in the Modes and Scenarios toolbar.

2.17.1.3 Editing a Custom Mode

To edit a custom mode:

1. From the **Edit** menu in SmartPower, choose **Modes and Scenarios > Custom Modes > Edit Custom Mode**, or right-click the mode in the Modes and Scenarios toolbar and select **Edit custom mode**. The Edit Custom Mode dialog box appears.

Figure 2-26. Edit Custom Mode Dialog Box



2. Edit the mode name and comments.
3. Click **OK**.


Note: You can only use the Edit Mode dialog box to edit the name and comment of the current mode. To edit the mode properties, such as clock and data frequencies, use the SmartPower tabs.

2.17.1.4 Copying a Custom Mode

To copy a custom mode:

1. Right-click the mode in the Modes and Scenarios toolbar and choose **Create a copy of this mode**. The New Custom Mode dialog box appears.

Figure 2-27. New Custom Mode Dialog Box




2. Edit the mode name and comments.
3. Click **OK**.

2.17.1.5 Deleting a Custom Mode

To delete a custom mode:

1. From the **Edit** menu in SmartPower, choose **Modes and Scenarios > Custom Modes > Delete Custom Mode**; or right-click the mode in the Modes and Scenarios toolbar, and select **Delete Mode**. This brings up the Delete Custom Mode dialog box. The Delete Custom Mode appears.

Figure 2-28. Delete Custom Mode Dialog Box



2. Select the mode from the pull down and click **OK**.

Note: You can delete only custom operating modes. You cannot delete predefined modes.

2.18 Scenarios

A scenario is a sequence of previously defined operating modes with a specific duration for each mode. When you create a new design, SmartPower will create predefined scenarios automatically that can be used as is, or copied to create a new scenario based on the predefined one.

Note: You cannot edit or delete predefined scenarios.

2.18.1 Creating a New Custom Scenario

To create a new custom scenario:

1. From the **Edit** menu in SmartPower, choose **Modes and Scenarios > Custom Scenarios > New Custom Scenario**; or click **Scenarios** in the Modes and Scenarios toolbar, and select **New custom scenario**.
2. Enter the scenario name, enter a duration (total duration for the sequence must equal to 100%) and select previously defined operating modes for this sequence.
3. Click **OK**.
The newly created scenario is set as default in the Modes and Scenarios toolbar.

2.18.2 Editing a Custom Scenario

To edit a custom scenario:

1. From the **Edit** menu in SmartPower, choose **Modes and Scenarios > Custom Scenarios > Edit Custom Scenario**; or right-click the scenario in the Modes and Scenarios toolbar, and select **Edit custom scenario**. The Edit Custom Scenario dialog box appears.

Figure 2-29. Edit Custom Scenario Dialog Box

	Duration (%)	Mode
1	50	Active
2	50	Flash*Freeze
3		
4		
5		
6		
7		
8		
9		

Total: 100 %

Comment:
Copied from "50% Flash*Freeze"

Buttons: Help, OK, Cancel


2. Edit the information.
3. Click **OK**.

2.18.3 Copying a Scenario

To copy a scenario:

1. Right-click the scenario in the Modes and Scenarios toolbar, and select **Create a copy of this scenario**. The New Custom Scenario dialog box appears.

Figure 2-30. New Custom Scenario Dialog Box



The dialog box titled "Power - New Custom Scenario" contains the following elements:

- Name:** A text field containing "Copy of scenario1".
- Table:** A table with 3 columns: an index (1-9), Duration (%), and Mode.

	Duration (%)	Mode
1	20	Active
2	80	Sleep
3		
4		
5		
6		
7		
8		
9		
- Total:** A label showing "100 %".
- Comment:** A text field containing "Copied from 'scenario1'".
- Buttons:** "Delete entry", "Help", "OK", and "Cancel".


2. Edit the information.
3. Click **OK**.

2.18.4 Deleting a Custom Scenario

To delete a custom scenario:

1. From the **Edit** menu in SmartPower, choose **Modes and Scenarios > Custom Scenarios > Delete Custom Scenario** or right-click the scenario in the Modes and Scenarios toolbar, and select **Delete Scenario**. The Delete Custom Scenario dialog box appears.

Figure 2-31. Delete Custom Scenario Dialog Box



The dialog box titled "Power - Delete Custom Scenario" contains the following elements:


- Choose the custom scenario to delete:** A pull-down menu showing "scenario1".
- Buttons:** "Help", "OK", and "Cancel".

2. Select the scenario from the pull down and click **OK**.

2.18.5 Breakdown by Instance

Using the **Breakdown by Instance** panel, you can include the breakdown by instance in the report and set specific options.

Figure 2-32. SmartPower Power Report Dialog Box - Breakdown By Instance Panel



Include Breakdown by Instance: shows the power consumption of each element that has been instantiated in the design: gates, nets, memories, and I/Os. The breakdown by instance can be filtered by:

- **Limit the number of reported instances to:** limits the number of instances reported to the specified number.
- **Report only instances with power greater than:** does not report instances with power consumption below the selected value.

This section can be sorted by selecting the preferred method:

- **Sort by:** sorts by name (alphabetical) or power values.
 - **Sort order:** sorts by ascending or descending order.
- Note:** The filter reduces the number of lines in the report by one per instance.

2.19 Power Reports

The Power report allows you to identify power consumption problems in your design. You can generate this report from the **Tools** menu and from SmartPower.

The Power Report dialog box is organized into the following panels:

- General
- Operating Conditions
- Options
- Breakdown by Instance
- Frequency Summary
- Probability Summary

2.19.1 Generating Power Reports from the Tools Menu

To generate Power reports from the **Tools** menu:

1. From the **Tools** menu, choose **Reports > Power** .
The Power Report dialog box appears.
2. Select the options you want to include in the report.
3. Click **OK**.
The Power Report appears in a separate window.

2.19.2 Generating Power Reports from within SmartPower


To generate Power reports from within SmartPower:

1. From the **Tools** menu, choose **Reports > Power Report** or click the **Report** button to open the Report dialog box. By default, the report includes global design information and a power summary.
2. Specify which results you want to display by selecting the categories and their options.

2.19.3 General

The **General** panel allows you to select what to include in the report, the report format, and the report mode.

Figure 2-33. SmartPower Power Report Dialog Box - General Panel



2.19.4 Include in the Report

Select the options you want to include in the Power report:

Power summary: reports the static, dynamic, and total power consumption of the design.

Breakdown by rail: shows the power consumption of each rail.

Breakdown by type: reports power consumption according to gates, nets, clocks, core static, I/Os, and memories.

Breakdown by clock domain: reports power consumption of each clock domain.

Thermal summary: includes a thermal report. The ambient temperature can be defined by operating conditions or ambient temperature.

When operating conditions is selected, the following characteristics are reported:

- Operating conditions
- Temperature range
- Junction temperature

When ambient temperature is selected, the following characteristics are reported:

- Ambient temperature
- Cooling style
- Package
- Thermal resistance Theta-JA
- Junction temperature
- Temperature range

- Junction temperature range limits specification

Battery life: reports the battery life.

Clock Domain summary: reports clock and data frequencies for each clock domain.

Operating Condition Summary: reports operating conditions.

Annotation Coverage: reports the number and percentage of pins annotated by each source (VCD, manual annotation, SDC constraint, vectorless estimation, and fixed values) for all clocks, register outputs, combinational outputs, set/reset nets, primary inputs, enable pins, and other pins.

2.19.5 Report Format

Select **Text**, **XML**, or **CSV** (comma-separated value) as the desired export format.


2.19.6 Mode

Select a mode for generating the report.

2.19.7 Operating Conditions

The **Operating Conditions** panel allows you to select the operating conditions for the current report.


Figure 2-34. SmartPower Power Report Dialog Box - Operating Conditions Panel



2.19.8 Options

The **Options** panel allows you to select power and frequency units and to use toggle rates.

Figure 2-35. SmartPower Power Report Dialog Box - Options Panel



2.19.8.1 Units

Frequency: sets unit preferences for frequency: Hz, KHz, MHz.

Power: sets unit preferences for power: W, mW, or uW.


2.19.8.2 Use Toggle Rates

When toggle rates are active (**Use Toggle Rates** box is checked), the data frequency of all the clock domains is defined as a function of the clock frequency. This updates the data frequency automatically when you update the clock frequency. Toggle rates allow you to specify the data frequency as a percentage of clock frequency; however, you can specify the data frequency only as a percentage of the clock frequency, not as a number. To set the data frequency again, clear the **Use Toggle Rates** option.

2.19.9 Breakdown by Instance

Using the **Breakdown by Instance** panel, you can include the breakdown by instance in the report and set specific options.

Figure 2-36. SmartPower Power Report Dialog Box - Breakdown By Instance Panel



Include Breakdown by Instance: shows the power consumption of each element that has been instantiated in the design: gates, nets, memories, and I/Os. The breakdown by instance can be filtered by:

- **Limit the number of reported instances to:** limits the number of instances reported to the specified number.
- **Report only instances with power greater than:** does not report instances with power consumption below the selected value.


This section can be sorted by selecting the preferred method:

- **Sort by:** sorts by name (alphabetical) or power values.
 - **Sort order:** sorts by ascending or descending order.
- Note:** The filter reduces the number of lines in the report by one per instance.

2.19.10 Frequency Summary

Using the **Frequency Summary** panel you can include the frequency summary in the report and set specific options.

Figure 2-37. SmartPower Power Report Dialog Box - Frequency Summary Panel



Include Frequency Summary: section shows the frequency summary and reports the pin, net, domain, frequency, and frequency source for each pin.

The frequency summary can be filtered by:

- **Limit the number of reported pins to:** limits the number of pins reported to the specified number.
- **Report only pins with frequencies greater than:** any pin with a frequency below the selected value is not reported.


This section can be sorted by selecting the preferred method:

- **Sort by:** sorts by pin name, net name, domain, frequency, or source.
- **Sort order:** sorts by ascending or descending order.

2.19.11 Probability Summary

Using the **Probability Summary** panel you can include the probability summary in the report and set specific options.


Figure 2-38. SmartPower Power Report Dialog Box - Probability Summary Panel



Include Probability Summary: shows the probability summary and reports the driver, net, rate, source, and type for each pin. This section can be sorted by selecting the preferred method:

- **Sort by:** sorts by pin name, net name, rate, source, or type.
- **Sort order:** sorts by ascending or descending order.

Figure 2-39. SmartPower Report



In addition to the information selected on the Power Reports dialog box, the report contains global design information.

Global design information: shows the target family, the package and the die. It also shows information about the operating conditions, speed grade, and power mode. This option is set by default.

2.20 Scenario Power Report

The Scenario Power report allows you to select a previously defined scenario and calculate the average power consumption and the battery life for this scenario. You can generate this report from the **Tools** menu and from within SmartPower.

The Scenario Power Report dialog box is organized into the following panels:

- General
- Operating Conditions
- Options
- Battery life

2.20.1 Generating Scenario Power Reports from the Tools Menu

Make sure your design contains one or more scenarios.

To generate a Scenario Power report from the **Tools** menu:

1. From the **Tools** menu, choose **Reports > Power > Scenario Power Report**.
The Scenario Power Report dialog box appears.
2. Select the options you want to include in the report, and then click **OK**.
The Scenario Power report appears in a separate window.

2.20.2 Generating Scenario Power Reports from within SmartPower

Make sure your design contains one or more scenarios.


To generate Scenario Power reports from within SmartPower:

1. From the **Tools** menu, choose **Reports > Scenario Power Report** or click the **Scenario Power Report** button to open the Power Scenarios dialog box. By default, the report includes global design information and power sequencer summary.
2. Specify which results you want to display by checking the boxes to be included in the report.

2.20.3 General

The **General** panel allows you to select what to include in the report, the report format, and the scenario for which you want to generate the report.

Figure 2-40. SmartPower Scenario Power Report Dialog Box – General Panel



2.20.4 Include in the report

Breakdown by rail: shows the power consumption of each rail.

Breakdown by type: reports on the power consumption according to: gates, nets, clocks, core static, I/Os, and memories.

Breakdown by mode: reports on power consumption by mode.

Operating condition summary: reports the operating conditions.

2.20.4.1 Report format

Select **Text** or **CSV** (comma-separated value) as the desired export format.


2.20.4.2 Scenario

Select a previously defined scenario to generate the report from.

2.20.5 Operating Conditions

The **Operating Conditions** panel allows you to select the operating conditions case for the current design.


Figure 2-41. SmartPower Scenario Power Report Dialog Box – Operating Conditions Panel



2.20.6 Options

The **Options** panel allows you to select power and frequency units and use toggle rates.

Figure 2-42. SmartPower Scenario Power Report Dialog Box – Options Panel



2.20.7 Units

Frequency: sets unit preferences for frequency (Hz, KHz, MHz).

Power: sets unit preferences for power (W, mW, or uW).

2.20.8 Use Toggle Rates


When toggle rates are active (**Use Toggle Rates** box is checked), the data frequency of all the clock domains is defined as a function of the clock frequency. This updates the data frequency automatically when you update the clock frequency. Toggle rates allow you to specify the data frequency as a percentage of clock frequency; however,

you can specify the data frequency only as a percentage of the clock frequency, not as a number. To set the data frequency again, clear the **Use Toggle Rates** option.

2.20.9 Battery life


The **Battery life** panel reports the battery capacity and the battery life. Enter a battery capacity in MA/Hrs.

Figure 2-43. SmartPower Scenario Power Report Dialog Box – Battery Life Panel



The SmartPower Scenario Power report returns the average power consumption and battery life for this sequence.

Figure 2-44. SmartPower Scenario Power Report



In addition to the information selected in the Scenario Power Reports dialog box, the report contains global design information, a mode summary, and the sequence average power.

Global design information: shows the target family, the package and the die. It also shows information about the operating conditions, speed grade, and power mode. This option is set by default.

Power Summary: reports the power consumption of the sequence by mode. This option is set by default.

Sequence Average Power: reports the average power consumption of the sequence. This option is set by default.

2.21 Activity and Hazards Reports

Traditional Power Analysis based on a VCD simulation file reports an average power value that will account for all nets switching in the design. This switching includes functional transitions and spurious transitions. Due to the delay of each gate, paths arriving at one internal gate may have different propagation delays. Therefore, a gate may exhibit multiple spurious transitions before settling to the correct logic level.

The Activity and Hazards Power report allows to identify gates and nets of the design that consume power because of spurious transitions. This is helpful to understand and further minimize power consumption. The activity and hazards report reads a VCD file and reports transitions and hazards for each clock cycle of the VCD file.

The Activity and Hazards report dialog box is organized into the following panels:

- General
- Partial Parsing
- Top-Level Name
- Glitch Filtering
- Clock Domains

2.21.1 Generating Activity and Hazard Reports from the Tools Menu

To generate Activity and Hazard reports from the **Tools** menu:

1. From the **Tools** menu, choose **Reports > Power > Activity and Hazards Report**.
The Activity and Hazards Power Report dialog box appears.
2. Select the options you want to include in the report, and then click **OK**.
The Activity and Hazards report appears in a separate window.


2.21.2 Generating Activity and Hazard Reports from within SmartPower

To generate Activity and Hazard reports from within SmartPower:

1. From the **Tools** menu, choose **Reports > Activity and Hazards Report**, or select a VCD file from the Modes and Scenarios toolbar and from the right-click menu, select **Tools > Power Activity and Hazards**.

2.21.3 General

Figure 2-45. SmartPower Activity and Hazards Report Dialog Box – General



VCD file: select the VCD file you want to import.

Report format: select **Text** or **CSV** (comma-separated value) as the desired export format.


Use operating conditions from: select the mode from which the operating conditions will be used.

Report type: select the report type:

- Report by Net – summary: summary report by net.
- Report by Net – detailed: detailed report by cycle.
- Report by Cycle – summary: summary report by net.
- Report by Cycle – detailed: detailed report by cycle. The selected report type reports activity and power for each net sorted by power in descending order and limits the number of reported nets to 40 by default. To change these options, click each option and from the pop-up menu, select the desired option:
 - Report: select the query report type: activity, power, or activity and power.
 - Sort by: select the query sort by functional power, functional transitions, spurious power, spurious transitions, or total power.
 - Sort order: select the query sort order: ascending or descending.
 - Limit the number of reported nets: enter the query filter limit.

2.21.4 Partial parsing


Figure 2-46. SmartPower Activity and Hazards Report Dialog Box – Partial Parsing



Partially parse VCD: specify the **Start time** and **End time** to partially parse the VCD file. This option can be used for large VCD files.

2.21.5 Top level name


Figure 2-47. SmartPower Activity and Hazards Report Dialog Box – Top-Level Name



This option allows you to select how the top-level name is specified. Select **Automatic detection** to let the VCD reader detect the top-level name of the design automatically or select **Specify** to specify the top-level name manually.

2.21.6 Glitch Filtering


Figure 2-48. SmartPower Activity and Hazards Report Advanced Options Dialog Box – Glitch Filtering



This option allows you to filter out pulses of short durations by selecting **Automatic glitch filtering** or by entering a value in the **Specify filtering threshold** field. The default glitch filtering option is **Automatic glitch filtering**.

2.21.7 Clock Domains

Figure 2-49. SmartPower Activity and Hazards Report Advanced Options Dialog Box – Clock Domains




The clock domain can be automatically constructed or specified by you.

Automatic construction: constructs the clock domain automatically. SmartPower analyzes your design automatically to assess if a clock is active and what is the active edge.

Specify: select this option to specify the period and first edge.

Use the clock domain table to set the active edge (rising, falling or both) and to set a clock as transparent. The results are displayed in the following Activity and Hazards Power report.

Figure 2-50. SmartPower Activity and Hazards Report



2.22 Export Report for Microchip Power Estimator (MPE)

This option exports an .xml report from SmartPower, which can be imported into the MPE tool. To export the MPE report, go to **Tools > Export Report for MPE**.

The generated .xml report contains the following information:


- Device Settings
- Thermal Settings
- Voltage Source
- Clocks
- Logic Breakdown
- LSRAM Breakdown with Advanced Settings
- uSRAM Breakdown with Advanced Settings
- Math Breakdown with Advanced Settings
- PLL and DLL
- I/Os
- Crypto
- Transceivers

In addition, the following information is available for PolarFire SoC devices:

- MSS RISC-V (Quad U54)
- AXI MSS/Fabric Interfaces
- MDDR
- MSS I/O Interfaces
- User Crypto

MPE has an import feature, which allows the user to import either the existing MPE spreadsheet (.xls format) or Power estimation results from Libero SoC SmartPower (.xml format), as shown in the following figure.

Figure 2-51. MPE with Import Data




2.23 Freeze/Unfreeze Calculations

Freeze/Unfreeze calculation option allows a more responsive User Interface and avoids runtime slowness due to a re-computation that occurs on every value changes. A toggle play pause button is provided to freeze the computation until the user is ready to re-compute. Only when the user clicks the play button, all the changes done will be computed and the User Interface gets updated.

To Freeze/Unfreeze Calculations, go to **Tools > Freeze/Unfreeze Calculations**.

Figure 2-52. Freeze/Unfreeze Calculations



2.24 Importing a VCD File

The Value Change Dump (VCD) file is a simulation file. The format of this file is specified in the IEEE 1364 standard.

You can configure the Project Manager to generate VCD files automatically using ModelSim. You can also generate a VCD file with a ModelSim simulator using the following commands:

```
vcd file example.vcd
vcd add -r /testbench/<top>_0/* run 1 us
vcd flush
```

This example creates a VCD file called example.vcd, adds all signals recursively, runs the simulation for one microsecond, and quits. You must quit ModelSim to obtain an accurate result from SmartPower.


If you have not completed the layout of the design, the design software guides you through place-and-route so you can import the VCD file. To annotate your VCD values to the design successfully, complete place-and-route even if you generated VCD files using timing simulation (pre-layout).

Note: SmartPower has been validated with VCD files generated by ModelSim. However, you may use any Verilog/VHDL simulator that offers a VCD dump feature.

For more information about how to generate a VCD file, refer to the user manual for your simulation tool.


1. From the **Simulation** menu, choose **Import VCD File**.
The Import VCD Options dialog box appears.

Figure 2-53. Import VCD File Dialog Box




2. Select the VCD file you want to import and select a mode to import it in, or click **New mode** and enter a mode name.
3. Select the options you want to specify.

Figure 2-54. Import VCD File Dialog Box — Partial Parsing




- **Partial parsing:** specify the **Start time** and **End time** to partially parse the VCD file. This option can be used for large VCD files.
 - **Top level name:** allows you to select how the top-level name is specified. The **Top level name** is the instance name of your design instantiated in the simulation testbench.
4. Select **Automatic detection** to let the VCD reader detect the top-level name of the design automatically or select **Specify** to specify the top-level name manually.

Figure 2-55. Import VCD File Dialog Box — Top-Level Name




- **Glitch filtering:** allows you to filter pulses of short durations by selecting **Automatic glitch filtering** or by entering a value in the **Specify filtering threshold** field. The default option is **Automatic glitch filtering**.
- **Remaining signals:** some signals may not be annotated by the VCD reader. This generally happens with VCD files created from a behavioral or a post-synthesis simulation. For those signals, you can either complete the annotation with the vectorless analysis or with the average values computed from the VCD file.

Figure 2-56. Import VCD File Dialog Box — Glitch Filtering



- **Filtering:** allows you to filter pulses of short durations by selecting **Automatic Glitch Filtering** or by entering a value in the **Specify Filtering Threshold** field. The default option is **Automatic Glitch Filtering**.
- **Remaining Signals:** some signals may not be annotated by the VCD reader. This generally happens with VCD files created from a behavioral or a post-synthesis simulation. For those signals, you can either complete the annotation with the vectorless analysis or with the average values computed from the VCD file.

Figure 2-57. Import VCD File Dialog Box — Remaining Signals



5. Click **OK**.

When the VCD file is imported successfully, the file appears under the imported mode in the Modes and Scenarios toolbar and the following messages appear in the Designer Log window:

Info:

```
VCD:34 glitch(es) filtered with 1000 ps threshold
```

The message above reports the number of glitches that have been filtered by the VCD reader.

Info:

```
VCD: Annotation Statistics Percentage of Annotated Pins:100.00 % Percentage of
Unannotated Pins:0.00 %
```

```
Percentage of Annotated Pins with Zero Frequency: 25.99 %
```

If the percentage of annotated pins is less than 50.00%, a warning message is generated.

If the percentage of annotated pins is low, you may want to verify that signals at all levels of hierarchy were added recursively (for example using `vcd add -r` in ModelSim).

If you simulate a pre-synthesis netlist or a post-synthesis RTL netlist, it is possible to get a low percentage of annotated pins. This happens because not all logic elements are in the pre-synthesis netlist and the post-synthesis RTL netlist. For accurate power estimation, it is best to run post-layout simulation with a back-annotated netlist.

To see which pins are not annotated, open the SmartPower **Frequencies** tab. If your file was imported successfully, a list of pins with annotated individual frequencies displayed with **VCD Import** appear as a source. The unannotated pins are displayed with **Default Estimation** as source. If your design has enable pins, open the SmartPower **Probabilities** tab.

After completing the import VCD process, you can create a custom mode based on the active mode. This custom mode will inherit all the clock and toggle frequencies of the active mode you set through the VCD import. This final step is optional. It gives you the flexibility to modify the active mode frequencies while saving the VCD scenario in SmartPower. For more information, refer to [2.17.1 Custom Operating Modes](#).

2.25 Removing a VCD File

The Value Change Dump (VCD) file is a simulation file whose format conforms to the IEEE 1364 standard.

To remove a VCD file, perform one of the following steps:

- Select the VCD file from Active mode or a custom mode, right-click the VCD file and select **Remove VCD File from <mode name> Mode**.
- From the **Simulation** menu, choose **Remove VCD File > <file name>**
Note: The annotation is removed when you remove the VCD file.

2.26 Auditing Files

When you start SmartPower, it performs an audit automatically. During the audit, SmartPower checks the time stamps of VCD files and reports any missing or out-of-date files. You can also initiate a file audit manually from the **Simulation** menu by choosing **Audit Files**. After an audit is run, an icon displaying the file status appears in the Modes and Scenarios toolbar next to the VCD file. Mousing over the icon displays more information.

Figure 2-58. Audit Files Results






Table 2-5. Audit Files Icons and Descriptions

Icon	Description
	Indicates that the VCD file has been modified
	Indicates that the VCD file is missing

To re-import the VCD file, right-click the VCD file and select **Re-import VCD File**. Then use the Import VCD Options dialog box to re-import the file.

3. Power Options

Allows you to set options that affect graphical and textual reports.

To open the SmartPower Power Options dialog box:



1. From the **File** menu, choose **Options**.
2. Select the **Options** panel in the Power Report dialog box.
3. Click the  icon in the SmartPower toolbar.

Figure 3-1. SmartPower Preferences Dialog Box




The dialog box has two sections: **Units** and **Use Toggle Rates**.

- **Units:** sets unit preferences for power (W, mW, and uW) and frequency (Hz, KHz, and MHz).
- **Use toggle rates:** when checked, the data frequency of all the clock domains is defined as a function of the clock frequency. This updates the data frequency automatically when you update the clock frequency. Toggle rates allow you to specify the data frequency as a percentage of clock frequency, but you can no longer specify the data frequency as a number, only as a percentage of the clock frequency. To specify data frequencies, clear the **Use toggle rates** option in the Preferences window.

You can set the data frequency percentage when you create a new clock domain with toggle rates active. In addition, when toggle rates are active you can set the data frequency percentage in the **Domain and Frequencies** tabs.

Figure 3-2. Create Clock Domain – Toggle Rates Enabled



4. Calculating Power

4.1 Calculating Power

Use the following steps to calculate the power consumption of your design. The list of screens and steps appear in the order in which you should view them to analyze your power accurately.

1. **Summary** tab: view global power at the design level and view its impact on junction temperature.
2. **Domains** tab: define clock domains and specify a clock frequency and a data frequency for each clock domain.
3. **Analysis** tab (optional): view detailed hierarchical analysis of your power consumption. If your power consumption exceeds your budget, this step helps you understand where there is room for improvement.
4. **Frequencies** tab (optional): specify individual pin frequencies. This step provides pin-by-pin control of the frequency.
5. **Probabilities** tab (optional): specify probabilities. You can use the default probabilities or set your own.

4.2 Extracting Power Consumption of a Specific Clock Domain

To calculate the power consumption of a single clock domain (clock tree and data path) in a design:

1. Set SmartPower in toggle-rate mode. This is the default setting. To confirm that SmartPower is in toggle-rate mode, choose **Preferences** from the **File** menu. Select the **Use Toggle Rates** check box.
2. In the **Domains** tab, set all the **Clock Frequencies** to zero except for the clock domain for which you are calculating the power consumption.

4.3 Advanced Analysis of I/Os

SmartPower allows you to estimate the power consumption related to I/Os. You can then analyze power consumption in detail.

To display I/O power consumption:

1. In the **Summary** tab, select **By Type** from the **Breakdown** drop-down list. The grid displays the total power consumption of all I/Os in the design, as well as all other components. If you use different I/O standards, and different Vcci power rails, you can also display the power consumption for each rail by selecting **By Rail** from the **Breakdown** drop-down list. **Breakdown By Rail** shows the power consumption and current for each Vcci rail in the design.
2. In the **Analysis** tab, select the highest hierarchy level in the Hierarchy tree in the left pane. Select **By Instance** from the Breakdown drop-down list.
3. In the **Analysis** tab, unselect all categories under **Instances Contributions** except I/Os, and then click **Apply**. The table then displays a list of all I/Os in the design, along with the power contribution of each individual I/O. The columns display important I/O attributes: external port name, load, standard, drive- strength, slew, and macro.
4. In the **Probabilities** tab, you can control the output probability of each tri-state and bidirectional I/O. The probability is the percentage of time that the I/O is used as an output. The default value can be changed and a specific value can also be set for each bidirectional or tri-state I/O.

4.4 Adding a New Clock Domain


When you run SmartPower, it researches your existing clock domains and partitions your design automatically.

You may want to review the list of clock domains in the **Domains** tab to ensure that all the clocks of your design are included in the list. Add or remove clocks as necessary.

To add a new clock domain:


1. Click the **Domains** tab, and then click the **Add Domain** button.
2. Select **Clock Domain** from the drop-down list.
The Create Clock Domain dialog box appears.

Figure 4-1. Create Clock Domain Dialog Box – Toggle Rates Disabled



3. To create a new clock, select a **Potential Clock Pin**, specify a clock and data frequency and click **Create**. The new clock domain appears in the Domains window. If you select an existing clock pin from the drop-down list, the lists of clock pins and data pins of this new clock domain are computed automatically based on the netlist topology.

Note: Select **Use Toggle Rates** in the SmartPower Preferences to define your data frequency as a percentage of your clock frequency. If your data frequency is 20% of your clock frequency, type **20** in the **Data Frequency** text box.



If you want to create an empty clock domain and fill the lists of clock-pins and data pins manually, do not select a clock pin. Instead, type a new name for your clock domain.

4.5 Verifying Lists of Clock and Data Pins of a Clock Domain

Beyond the verification of the list of clock domains, you may also wish to verify that the lists of clock pins and data pins computed for each clock domain are correct.

To verify the lists of clock pins and data pins of a clock domain:

1. Click the **Domains** tab and select a specific **Domain** in the list.
2. **Display the list of clock pins or data pins of this Domain.** A drop-down list in the **Domains** tab allows you to select clock pins or data pins. SmartPower displays the list of pins corresponding to your selection below the drop-down list. You can add or remove clock pins and data pins as necessary.
3. **Remove a pin from a clock domain.** Highlight the selected pin and click the **Remove** button. The pin is removed from the clock domain and is made available in the list of pins that you can add in another clock domain.
4. Highlight the selected pin in the list of pins that are not yet in a domain and click the **Add** button to add a pin in a clock domain.

This pin is added to the clock domain. The pin is a clock or data pin, depending on the specification of the drop-down list when you clicked the **Add** button.

Note: You cannot add a pin that exists in another domain until you free it from its existing domain. The pin is unavailable until you remove it from that domain.


After you verify that all the clocks of your designs are correctly identified and constructed, specify the correct clock and data frequency for each clock domain.

4.6 Adding a New Set of Pins

To add a new set of pins:

1. Open the Create Clock Domain dialog box.
2. Click the **Domains** tab and click the **Add Domain** button.
3. Select **Set of Pins** from the drop-down list.
4. **Create a Set of Pins.** Name your new set of pins, specify a data frequency, and click **Create**

Figure 4-2. Create Set of Pins Dialog Box



The new set of pins appears in the Domains window.

4.7 Specifying Clock and Data Frequencies in SmartPower

To specify a clock and data frequency:

1. Click the **Domains** tab.
2. Select the **Clock/Data** frequency cell and enter a new value.

SmartPower defaults to 0 MHz for the clock frequency. Import your clock frequency from SmartTime by using the Initialize Frequencies dialog box in SmartPower or input your target for each clock frequency in the **Domains** tab. You must also specify a data frequency (5% of your clock frequency is a typical guideline for your data frequency – this corresponds to a toggle rate of 10%).

Not all the pins/gates/nets of your design are associated with a specific clock. For example, the frequency of a design input port is not always correlated to a clock frequency. By extension, all pins that are upstream of the first level of sequential elements are not associated with any clock. SmartPower creates an InputSet by default that it uses to group all the pins that are controlled by design inputs (instead of sequential elements). You may want to view and verify the InputSet to further evaluate your design.

4.8 Verifying the InputSet

To verify the InputSet:

1. Click the **Domains** tab and select the domain named **InputSet** in the list.
2. Verify the list of pins of this domain. All the input ports of your design (except the clocks) belong in the **InputSet**. All pins between these input ports and the first level of sequential elements belong in the **InputSet**. You can add or remove pins as necessary.
3. Specify an average input frequency. SmartPower uses the same frequency for all pins of the InputSet. The default InputSet frequency is 1 MHz. Enter a new value to change it.

4.9 Splitting the InputSet

You might want to split the InputSet into several sets in order to specify different frequencies. For example, you might want to create a ResetSet — a reset tree with a very low frequency.

To split the InputSet:

1. Create a new set of pins: In the **Domains** tab, click the **New** button, and select **Set of Pins** from the drop-down menu.
2. In the Create Set of Pins dialog box, type a name and a frequency for the new set and click **Create**. The new set of pins appears in the Domains window. You can only create an empty set of pins, but it is possible to add pins to this domain later.
3. Remove a group of pins from the **InputSet**. Click the **Domains** tab and select the domain named **InputSet** in the list.

4. Select the pins that you want to remove and click the **Remove** button.

4.10 Specifying Individual Pin Frequencies

The **Frequencies** tab allows you to specify an average clock and data frequency for each clock domain, and also an average frequency for each set of pins. This gives you an initial estimate of the power consumption of your design. However, if this estimate is not sufficiently accurate, you can refine it with a pin-by-pin annotation of the frequency.

The following procedure describes how to set the frequency of an individual pin. Performing this procedure does not remove the pin from its clock domain. A frequency annotation merely overrides the domain level frequency.

1. Locate the pin in the **Frequencies** tab. You may need to select different clock domains from the drop-down list on the **Frequencies** tab. You can use filters to facilitate this search.
2. Select the pin(s) in the grid and click the **Set frequencies for selected pins** button.
3. Enter a new frequency value and click **OK**. This specifies a new frequency for the selected pin(s).

4.11 Changing the Frequency Annotation of a Pin

The following procedure describes how to change the frequency annotation of an individual pin. This may be useful when you import a VCD (value change-dump) file (see).

1. Locate the pin in the **Frequencies** tab. You may need to select different clock domains from the drop-down list on the **Frequencies** tab. You can use filters to facilitate the search.
2. Select the pin(s) in the grid and click the **Set frequency for selected pins** button.
3. Enter a new frequency value and click **OK**. This specifies a new frequency for the selected pin(s).

4.12 Removing the Frequency Annotation of a Pin

This procedure describes how to remove the frequency annotation of an individual pin. This may be useful when you import a VCD (value change-dump) file.

1. Locate the pin in the **Frequencies** tab. You may need to select different clock domains from the drop-down menu on the **Frequencies** tab. You can use filters to facilitate the search.
2. Select the pin(s) in the grid and click the **Reset frequencies for selected pins** button. This removes the specified frequency from the selected pins.

4.13 Specifying Individual Pin Probabilities

The **Probabilities** tab allows you to specify the default output probability value for memory blocks, and tristate and bidirectional I/Os. In addition, you can increase the accuracy of the power estimation by annotating the probability of specific pins.

To specify or change the probability for one or multiple pins:

1. Locate the pin(s) in the **Probabilities** tab. You can use filters to facilitate this search.
2. Select the pin(s) and click the **Set probabilities for selected pins** button.
3. Enter a new probability value and click **OK**.

4.13.1 Specifying or Changing Probability for One or More Pins

To specify or change the probability for one or multiple pins:

1. Locate the pin(s) in the **Probabilities** tab. You can use filters to facilitate this search.
2. Select the pin(s) and click the **Set probabilities for selected pins** button.
3. Enter a new probability value and click **OK**.

4.13.2 Resetting the Probability for One or More Pins

To reset the probability for one or multiple pins:


1. Locate the pin(s) in the **Probabilities** tab. You can use filters to facilitate this search.
2. Select the pin(s) and click the **Reset Probabilities for selected pins** button.

4.14 Vectorless Estimation

The Vectorless estimation method is an accurate method of annotating individual pins with frequencies and probabilities. It uses primary inputs, clock frequencies, and nets annotated with other methods as a starting point, and uses a Monte Carlo simulation to annotate all nets in the design with frequencies and probabilities.

Vectorless estimation is available for SmartFusion2, IGLOO2, RTG4, PolarFire and PolarFire SoC families of devices.

Vectorless estimation can be enabled from the Initialize Frequencies and Probabilities dialog box or from the VCD Import dialog box.

Changes to probabilities or frequencies in the Probabilities, Frequencies, or Domains tabs result in an out-of-date vectorless estimation. To update vectorless estimation, press the refresh vectorless  button.

4.15 Viewing Results (Design Level)

Click the **Summary** tab to view global power consumption at the design level. The **Summary** tab shows your design's estimated power consumption and temperature information.

The power estimation reported in the **Summary** tab is the total static and dynamic power consumption of your design. For a more detailed view of this power consumption, click the **Analysis** tab.

To estimate the junction temperature:

1. Verify your package. You cannot change your package directly in SmartPower, because it may render your place-and-route information (and thus it may severely impact the total power consumption). To choose another package, use **Designer > Tools > Device Selection**.
2. Click the **Summary** tab and select a **Cooling** style in the list. Thermal resistance changes automatically when you update the cooling style.
3. Specify an ambient temperature. Enter an **ambient temperature** (default value is 25°C) and click the **Set** button.

Note: The junction temperature value changes according to the package, cooling style, and ambient temperature values you choose.

4.16 Analyzing Results


The **Analysis** tab shows the estimated power consumption of individual blocks, gates, nets, I/Os, and memory, and allows you to make a hierarchical analysis of your power consumption.

The **Analysis** tab may also help you to improve your power consumption by identifying the components that consume a significant amount of power.

To identify the components consuming the most power:

1. Use the **Analysis** tab to expand the design hierarchy. The **Analysis** tab allows you to expand your design hierarchy and view a complete list of the blocks in your design. In the hierarchy window, click the **+** next to your design to view the items in the hierarchy. Click the **+** next to a sub-block to view its sub-elements.

Figure 4-3. Analysis Tab Dialog Box



2. Click to select a block. By default, SmartPower selects the design-level block, but you can always select another block in the hierarchical tree. The Report window displays the list of sub-elements of the selected block. Initially, this list includes all sub-elements. The grid in the Analysis window displays a breakdown of the power of the selected block by type. This breakdown provides you a good overview of which areas of your design you should optimize for power.
3. To find the components that use a significant amount of power, choose **By Instance** from the **Breakdown** drop-down list.
4. Sort and filter the sub-elements to find the component that is using the most power. The Analysis window displays the list of sub-elements of the selected block. By default, this list includes all sub-elements. The grid contains columns for name, type, power, driver, fanout, macro, I/O standard, output load, output drive, slew, port, domain and frequency. You can limit the list of sub-elements to a list of sub-blocks, nets, gates, I/Os, memories, or any combination of these five classes of sub-elements. You can sort the list according to any column by double-clicking the column header.

4.17 SmartPower Calculation Equations

SmartPower calculates the static power and the dynamic power of your design, for given operating conditions and operating modes:

Static Power: summation of the static power consumed by each element of the design. SmartPower provides a static power consumption of the array. This value is die-dependent. This value is also a function of the operating mode. For some families, SmartPower also considers a static power contribution per I/O bank. For specific I/O technologies like voltage referenced I/Os or differential I/Os, SmartPower also considers a static power contribution per I/O.

Dynamic Power: summation of the dynamic power consumed by each element of the design (nets, modules, I/Os, RAMs, FIFOs, PLLs, etc.).

Operating Conditions: SmartPower calculates power consumption in Worst, Typical, or Best operating conditions. SmartPower uses the following as general guidelines:

- It applies a voltage derating to dynamic power contributions. Higher voltage typically leads to higher power consumption.

- It applies a temperature derating to static power contributions. Higher temperature typically leads to higher power consumption.
- It applies no radiation derating.

Operating Modes: SmartPower calculates power consumption in Active, Static, Flash*Freeze, Sleep, and Shutdown operating modes when applicable for your design.

4.18 Sample Equations:

The following examples are for general evaluation purposes only. They are not a precise representation of the actual calculations, since each calculation takes into account family-specific information.

- For a **net**,

$$P = C \cdot V^2 \cdot F$$

where C is the total capacitive loading of the net (extracted from the routing topology), V is the net's voltage swing, and F is the average switching frequency.

Note: For the ProASICPLUS family, SmartPower extracts the capacitive loading of a net from a Wire Load model.

- For a **module**, the power is computed using a characterized library (by family and die-size) describing a specific power model for each type of module. For example, the power model of a flip-flop is given by

$$P = P_{CK} \cdot F_{CK} + P_{DOUT} \cdot F_{DOUT} + P_{Din} \cdot F_{Din}$$

where FCK is the average clock-input frequency for this flip-flop, FDOUT is its average data-output frequency, and PCK, PDOUT, PDin are three constants estimated by electrical simulation and silicon characterization for this flip-flop module, and FDin is its average data-input frequency.

- For an **I/O**, the formula used for computing the power consumption depends on the I/O technology and the family. For example, for a TTL output, the dynamic power is given by

$$P = P_{INT} \cdot F + C \cdot V^2 \cdot F$$

where C is the output load (derived from what you have set in the I/O Attribute Editor GUI, typically 35 pF for TTL), V is the output's voltage swing (3.3 V for TTL), and PINT represents an internal power contribution dissipated in the pad, and F is the average switching frequency of the I/O.

- For a **complex block**, like a RAM, a FIFO, or a PLL, SmartPower uses a high-level power model that integrates design parameters.

SmartPower computes all the constant parameters of these equations automatically. However, the frequencies depend on the target frequencies of your design. Since it is impractical to enter each frequency manually, SmartPower has several flows that help you estimate the frequencies and calculate the power consumption.

4.19 Data Change History - SmartPower

The data change history report lists power data updates up to the current release that may impact the power consumption of the design.

To generate a data change history report, choose **Data Change History** from the **Help** menu to open a data change history report in text format.

5. SmartPower Tcl Commands

Refer to the following documents for detailed information about Tcl commands supported by SmartPower:

- [SmartFusion2, IGLOO2, RTG4 Tcl Commands Reference Guide](#)
- [PolarFire FPGA Tcl Commands Reference Guide](#)

6. Revision History

Revision	Date	Description
B	04/2021	The following changes are made in this revision: <ul style="list-style-type: none">• Updated section Export Report for Microchip Power Estimator (MPE).• Added section Freeze/Unfreeze Calculations.
A	11/2020	Document converted to Microchip template. Initial Revision.

7. Microchip FPGA Technical Support

Microchip FPGA Products Group backs its products with various support services, including Customer Service, Customer Technical Support Center, a website, and worldwide sales offices. This section provides information about contacting Microchip FPGA Products Group and using these support services.

7.1 Customer Service

Contact Customer Service for non-technical product support, such as product pricing, product upgrades, update information, order status, and authorization.

- From North America, call **800.262.1060**
- From the rest of the world, call **650.318.4460**
- Fax, from anywhere in the world, **650.318.8044**

7.2 Customer Technical Support

Microchip FPGA Products Group staffs its Customer Technical Support Center with highly skilled engineers who can help answer your hardware, software, and design questions about Microchip FPGA Products. The Customer Technical Support Center spends a great deal of time creating application notes, answers to common design cycle questions, documentation of known issues, and various FAQs. So, before you contact us, please visit our online resources. It is very likely we have already answered your questions.

You can communicate your technical questions through our Web portal and receive answers back by email, fax, or phone. Also, if you have design problems, you can upload your design files to receive assistance. We constantly monitor the cases created from the web portal throughout the day. When sending your request to us, please be sure to include your full name, company name, and your contact information for efficient processing of your request.

Technical support can be reached at soc.microsemi.com/Portal/Default.aspx.

For technical support on RH and RT FPGAs that are regulated by International Traffic in Arms Regulations (ITAR), log in at soc.microsemi.com/Portal/Default.aspx, go to the **My Cases** tab, and select **Yes** in the ITAR drop-down list when creating a new case. For a complete list of ITAR-regulated Microchip FPGAs, visit the ITAR web page.

You can track technical cases online by going to [My Cases](#).

7.3 Website

You can browse a variety of technical and non-technical information on the Microchip FPGA Products Group [home page](#), at www.microsemi.com/soc.

7.4 Outside the U.S.

Customers needing assistance outside the US time zones can either contact technical support at (<https://soc.microsemi.com/Portal/Default.aspx>) or contact a local sales office.

Visit [About Us](#) for [sales office listings](#) and [corporate contacts](#).

The Microchip Website

Microchip provides online support via our website at www.microchip.com/. This website is used to make files and information easily available to customers. Some of the content available includes:

- **Product Support** – Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- **General Technical Support** – Frequently Asked Questions (FAQs), technical support requests, online discussion groups, Microchip design partner program member listing
- **Business of Microchip** – Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

Product Change Notification Service

Microchip's product change notification service helps keep customers current on Microchip products. Subscribers will receive email notification whenever there are changes, updates, revisions or errata related to a specified product family or development tool of interest.

To register, go to www.microchip.com/pcn and follow the registration instructions.

Customer Support

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- Local Sales Office
- Embedded Solutions Engineer (ESE)
- Technical Support

Customers should contact their distributor, representative or ESE for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in this document.

Technical support is available through the website at: www.microchip.com/support

Microchip Devices Code Protection Feature

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specifications contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is secure when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods being used in attempts to breach the code protection features of the Microchip devices. We believe that these methods require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Attempts to breach these code protection features, most likely, cannot be accomplished without violating Microchip's intellectual property rights.
- Microchip is willing to work with any customer who is concerned about the integrity of its code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of its code. Code protection does not mean that we are guaranteeing the product is "unbreakable." Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Legal Notice

Information contained in this publication is provided for the sole purpose of designing with and using Microchip products. Information regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications.

THIS INFORMATION IS PROVIDED BY MICROCHIP "AS IS". MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE OR WARRANTIES RELATED TO ITS CONDITION, QUALITY, OR PERFORMANCE.

IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL OR CONSEQUENTIAL LOSS, DAMAGE, COST OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE INFORMATION OR ITS USE, HOWEVER CAUSED, EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE. TO THE FULLEST EXTENT ALLOWED BY LAW, MICROCHIP'S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THE INFORMATION OR ITS USE WILL NOT EXCEED THE AMOUNT OF FEES, IF ANY, THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THE INFORMATION. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Trademarks

The Microchip name and logo, the Microchip logo, Adaptec, AnyRate, AVR, AVR logo, AVR Freaks, BesTime, BitCloud, chipKIT, chipKIT logo, CryptoMemory, CryptoRF, dsPIC, FlashFlex, flexPWR, HELDO, IGLOO, JukeBlox, KeeLoq, Kleer, LANCheck, LinkMD, maXStylus, maXTouch, MediaLB, megaAVR, Microsemi, Microsemi logo, MOST, MOST logo, MPLAB, OptoLyzer, PackTime, PIC, picoPower, PICSTART, PIC32 logo, PolarFire, Prochip Designer, QTouch, SAM-BA, SenGenuity, SpyNIC, SST, SST Logo, SuperFlash, Symmetricom, SyncServer, Tachyon, TimeSource, tinyAVR, UNI/O, Vectron, and XMEGA are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

AgileSwitch, APT, ClockWorks, The Embedded Control Solutions Company, EtherSynch, FlashTec, Hyper Speed Control, HyperLight Load, IntelliMOS, Libero, motorBench, mTouch, Powermite 3, Precision Edge, ProASIC, ProASIC Plus, ProASIC Plus logo, Quiet-Wire, SmartFusion, SyncWorld, Temux, TimeCesium, TimeHub, TimePictra, TimeProvider, WinPath, and ZL are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Adjacent Key Suppression, AKS, Analog-for-the-Digital Age, Any Capacitor, AnyIn, AnyOut, Augmented Switching, BlueSky, BodyCom, CodeGuard, CryptoAuthentication, CryptoAutomotive, CryptoCompanion, CryptoController, dsPICDEM, dsPICDEM.net, Dynamic Average Matching, DAM, ECAN, Espresso T1S, EtherGREEN, IdealBridge, In-Circuit Serial Programming, ICSP, INICnet, Intelligent Paralleling, Inter-Chip Connectivity, JitterBlocker, maxCrypto, maxView, memBrain, Mindi, MiWi, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICKit, PICtail, PowerSmart, PureSilicon, QMatrix, REAL ICE, Ripple Blocker, RTAX, RTG4, SAM-ICE, Serial Quad I/O, simpleMAP, SimpliPHY, SmartBuffer, SMART-I.S., storClad, SQL, SuperSwitcher, SuperSwitcher II, Switchtec, SynchroPHY, Total Endurance, TSHARC, USBCheck, VariSense, VectorBlox, VeriPHY, ViewSpan, WiperLock, XpressConnect, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

The Adaptec logo, Frequency on Demand, Silicon Storage Technology, and Symmcom are registered trademarks of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2021, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

ISBN: 978-1-5224-7806-5

Quality Management System

For information regarding Microchip's Quality Management Systems, please visit www.microchip.com/quality.

Worldwide Sales and Service

AMERICAS	ASIA/PACIFIC	ASIA/PACIFIC	EUROPE
Corporate Office 2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277 Technical Support: www.microchip.com/support Web Address: www.microchip.com	Australia - Sydney Tel: 61-2-9868-6733 China - Beijing Tel: 86-10-8569-7000 China - Chengdu Tel: 86-28-8665-5511 China - Chongqing Tel: 86-23-8980-9588 China - Dongguan Tel: 86-769-8702-9880 China - Guangzhou Tel: 86-20-8755-8029 China - Hangzhou Tel: 86-571-8792-8115 China - Hong Kong SAR Tel: 852-2943-5100 China - Nanjing Tel: 86-25-8473-2460 China - Qingdao Tel: 86-532-8502-7355 China - Shanghai Tel: 86-21-3326-8000 China - Shenyang Tel: 86-24-2334-2829 China - Shenzhen Tel: 86-755-8864-2200 China - Suzhou Tel: 86-186-6233-1526 China - Wuhan Tel: 86-27-5980-5300 China - Xian Tel: 86-29-8833-7252 China - Xiamen Tel: 86-592-2388138 China - Zhuhai Tel: 86-756-3210040	India - Bangalore Tel: 91-80-3090-4444 India - New Delhi Tel: 91-11-4160-8631 India - Pune Tel: 91-20-4121-0141 Japan - Osaka Tel: 81-6-6152-7160 Japan - Tokyo Tel: 81-3-6880-3770 Korea - Daegu Tel: 82-53-744-4301 Korea - Seoul Tel: 82-2-554-7200 Malaysia - Kuala Lumpur Tel: 60-3-7651-7906 Malaysia - Penang Tel: 60-4-227-8870 Philippines - Manila Tel: 63-2-634-9065 Singapore Tel: 65-6334-8870 Taiwan - Hsin Chu Tel: 886-3-577-8366 Taiwan - Kaohsiung Tel: 886-7-213-7830 Taiwan - Taipei Tel: 886-2-2508-8600 Thailand - Bangkok Tel: 66-2-694-1351 Vietnam - Ho Chi Minh Tel: 84-28-5448-2100	Austria - Wels Tel: 43-7242-2244-39 Fax: 43-7242-2244-393 Denmark - Copenhagen Tel: 45-4485-5910 Fax: 45-4485-2829 Finland - Espoo Tel: 358-9-4520-820 France - Paris Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79 Germany - Garching Tel: 49-8931-9700 Germany - Haan Tel: 49-2129-3766400 Germany - Heilbronn Tel: 49-7131-72400 Germany - Karlsruhe Tel: 49-721-625370 Germany - Munich Tel: 49-89-627-144-0 Fax: 49-89-627-144-44 Germany - Rosenheim Tel: 49-8031-354-560 Israel - Ra'anana Tel: 972-9-744-7705 Italy - Milan Tel: 39-0331-742611 Fax: 39-0331-466781 Italy - Padova Tel: 39-049-7625286 Netherlands - Drunen Tel: 31-416-690399 Fax: 31-416-690340 Norway - Trondheim Tel: 47-72884388 Poland - Warsaw Tel: 48-22-3325737 Romania - Bucharest Tel: 40-21-407-87-50 Spain - Madrid Tel: 34-91-708-08-90 Fax: 34-91-708-08-91 Sweden - Gothenberg Tel: 46-31-704-60-40 Sweden - Stockholm Tel: 46-8-5090-4654 UK - Wokingham Tel: 44-118-921-5800 Fax: 44-118-921-5820