



ReadMe file for QN132 PCB Land Pad Design(0)(Via-InP)(VL300)

To View Top Layer of PCB routing in the AutoCAD file these layers must be on;





To View Bottom Layer of PCB routing in the AutoCAD file these layers must be on;

