UG0468 User Guide Space Vector Modulation v4.1





Power Matters.™

Microsemi Corporate Headquarters
One Enterprise, Aliso Viejo,
CA 92656 USA
Within the USA: +1 (800) 713-4113
Outside the USA: +1 (949) 380-6100
Fax: +1 (949) 215-4996
Email: sales.support@microsemi.com
www.microsemi.com

© 2016 Microsemi Corporation. All rights reserved. Microsemi and the Microsemi logo are trademarks of Microsemi Corporation. All other trademarks and service marks are the property of their respective owners.

Microsemi makes no warranty, representation, or guarantee regarding the information contained herein or the suitability of its products and services for any particular purpose, nor does Microsemi assume any liability whatsoever arising out of the application or use of any product or circuit. The products sold hereunder and any other products sold by Microsemi have been subject to limited testing and should not be used in conjunction with mission-critical equipment or applications. Any performance specifications are believed to be reliable but are not verified, and Buyer must conduct and complete all performance and other testing of the products, alone and together with, or installed in, any end-products. Buyer shall not rely on any data and performance specifications or parameters provided by Microsemi. It is the Buyer's responsibility to independently determine suitability of any products and to test and verify the same. The information provided by Microsemi hereunder is provided "as is, where is" and with all faults, and the entire risk associated with such information is entirely with the Buyer. Microsemi does not grant, explicitly or implicitly, to any party any patent rights, licenses, or any other IP rights, whether with regard to such information itself or anything described by such information. Information provided in this document is proprietary to Microsemi, and Microsemi reserves the right to make any changes to the information in this document or to any products and services at any time without notice.

About Microsemi

Microsemi Corporation (Nasdaq: MSCC) offers a comprehensive portfolio of semiconductor and system solutions for aerospace & defense, communications, data center and industrial markets. Products include high-performance and radiation-hardened analog mixed-signal integrated circuits, FPGAs, SoCs and ASICs; power management products; timing and synchronization devices and precise time solutions, setting the world's standard for time; voice processing devices; RF solutions; discrete components; enterprise storage and communication solutions, security technologies and scalable anti-tamper products; Ethernet solutions; Power-over-Ethernet ICs and midspans; as well as custom design capabilities and services. Microsemi is headquartered in Aliso Viejo, California, and has approximately 4,800 employees globally. Learn more at www.microsemi.com.



Contents

1	Revis	ion History			
	1.1	Revision 5.0			
	1.2	Revision 4.0			
	1.3	Revision 3.0			
	1.4	Revision 2.0			
	1.5	Revision 1.0			
2	Introduction				
	2.1	Min-Max Method			
3	Hardware Implementation				
_	3.1	Inputs and Outputs			
	3.2	Timing Diagram			
	3.3	Resource Utilization			



Figures

Figure 1	Sinusoidal PWM Waveform	2
Figure 2	SVM Min-Max Method	3
Figure 3	SVM Hardware Block Diagram	4
Figure 4	SVM Timing Diagram	5



Tables

Table 1	Inputs and Outputs of SVM
Table 2	SVM Resource Utilization



1 Revision History

The revision history describes the changes that were implemented in the document. The changes are listed by revision, starting with the most current publication.

1.1 **Revision 5.0**

The following is a summary of the changes in revision 5.0 of this document.

- Added the IP version to the document title.
- Removed Configuration Parameter section from Hardware Implementation, page 4.

1.2 **Revision 4.0**

Removed FSM related information from SVM Hardware Implementation and Configuration Parameters sections (SAR 69654).

1.3 **Revision 3.0**

Changed the block name from SVPWM to SVM throughout the document (SAR 64768).

1.4 **Revision 2.0**

The following is a summary of the changes in revision 2.0 of this document.

- Updated the title of the user guide (SAR 63243).
- Updated Min-Max Method, page 2 section and removed Direct Injection of Third Harmonic section (SAR 63243).
- Updated Table 1, page 4 and Table 2, page 5 (SAR 63243).
- Removed Appendix (SAR 63243).

1.5 Revision 1.0

Revision 1.0 was the first publication of this document.




2 Introduction

Space vector modulation (SVM) is an improved technique for generating a fundamental sine wave that provides a higher voltage to the motor in a 3-phase system, lower total harmonic distortion, and controls the number of short pulses in the PWM waveform.

A sinusoidal PWM drive cannot provide a line-line output voltage as high as the line supply.

Figure 1 • Sinusoidal PWM Waveform



SVM is a technique that is used to increase the output voltage of PWM drive and reduce the number of short pulses. The strategy used in SVM technique is to modify the modulation of sine waves (input phase voltages) to increase the inverter voltage gain and also to reduce inverter losses.

2.1 Min-Max Method

There are many techniques to implement SVM out of which Min-Max method requires least computation and is used in the IP block. The third harmonic voltage is generated from min and max values of instantaneous 3-phase reference voltages. The third harmonic voltage (V_{3H}) is calculated as:

$$V_{3H} = \frac{\max(V_a, V_b, V_c) + \min(V_a, V_b, V_c)}{2}$$



The computed third harmonic voltage is added to each phase voltage to get space vector modulated reference.


$$V_{SA} = V_A - V_{3H}$$

$$V_{SB} = V_B - V_{3H}$$

$$V_{SC} = V_C - V_{3H}$$

The addition of third harmonic reduces the peak of the reference signal by 15% and hence allows more fundamental without reaching over-modulation. Even though third harmonic is added in phase voltages, it does not appear in line voltages because it is common mode voltage. As a result, there is no third harmonic current but only fundamental current. For a given modulation index, the peak modulation voltage is farther from the peak carrier voltage. Thus, the number of short pulses is minimized. To utilize the DC bus fully, the voltages must be scaled up by 15% in one of the blocks that follows the SVM in the FOC loop.

Figure 2 • SVM Min-Max Method




If the output should be a unity peak value and the reduction in peak introduced by the block is 0.866, the factor k must be 1.155 (k * 0.866 = 1, k=1/0.866). This implies that there is a 15.5 percent boost introduced in the phase voltage, which results in better utilization of the DC bus.



3 Hardware Implementation

The following figure shows the block diagram of the SVM block implemented.

Figure 3 • SVM Hardware Block Diagram



The SVM block is a control unit which implements the Min-Max method discussed in the Min-Max Method, page 2. The computations involved in the Min-Max method are performed within the block.

The entire system is synchronized with a system clock given to sys_clk_i and controlled by a finite state machine (FSM) and then implemented in the SVM block.

3.1 Inputs and Outputs

The following table lists the description of the input and output ports of the SVM block.

Table 1 • Inputs and Outputs of SVM


Signal Name	Direction	Description
sys_clk_i	Input	System clock
reset_i	Input	Active Low asynchronous reset signal to design
start_i	Input	A single bit start signal that must go high for one clock cycle to start SVM computations
va_i	Input	Input phase voltage (va)
vb_i	Input	Input phase voltage (vb)
vc_i	Input	Input phase voltage (vc)
va3h_o	Output	Output voltage signal corresponding to input phase voltage va_i, with the third harmonic component
vb3h_o	Output	Output voltage signal corresponding to input phase voltage vb_i, with the third harmonic component
vc3h_o	Output	Output voltage signal corresponding to input phase voltage vc_i, with the third harmonic component
done_o	Output	A single bit signal which goes High for one clock cycle to indicate that all the computations are done and output corresponding to given inputs is obtained



3.2 Timing Diagram

The following figure shows the timing diagram of the SVM block.

Figure 4 • SVM Timing Diagram



3.3 Resource Utilization

The following table lists the resource utilization report of the SVM in the SmartFusion[®]2 system-on-chip (SoC) field programmable gate array (FPGA) device.

Table 2 • SVM Resource Utilization

Resource	Usage
Sequential elements	90
Combinational logic	240
MACC	0
RAM1kx18	0
RAM64x18	0