



Note 1: This short is manually performed upon completion of the PCB layout in order to connect both grounds at a single point

Note 2: These signals are optically coupled in order to achieve 1500 VRMS isolation.

Remarks : an 'x' preceding the net name defines the active low digital function.

This document contains confidential information that is legally privileged of Microsemi. Any disclosure, copying or distribution of any of the information contained in this document is STRICTLY PROHIBITED			
Title		Approvals	
Ori marketing		Designed	Date
Doc. No. 01-1358-E01		Drawn	S.A 13.10.10
Part. No. PD-1358-201		Checked	T.Z 13.10.10
Size A3		Approved	T.Z 13.10.10
Rev 007		Last modifi	Z.S 12.03.18
Sheet 1 of 1	Scale		