

## TOTAL IONIZING DOSE TEST REPORT

No. 04T-RT54SX72S(U)-D0Y311  
August 4, 2004

*J.J. Wang*  
(650) 318-4576  
[jih-jong.wang@actel.com](mailto:jih-jong.wang@actel.com)

### I. SUMMARY TABLE

Parameter	Tolerance
1. Gross Functionality	Passed 100 krad (Si)
2. Power Supply Current ( $I_{CCA}/I_{CCI}$ )	Passed 62.6 krad (Si) using 25-mA spec. Post 100 krad (Si) and after 90 days room temperature annealing: average $I_{CCA} = 100$ mA, and average $I_{CCI} = 48.3$ mA.
3. Input Threshold ( $V_{TIL}/V_{IH}$ )	Passed 100 krad (Si)
4. Output Drive ( $V_{OL}/V_{OH}$ )	Passed 100 krad (Si)
5. Propagation Delay	Passed 100 krad (Si) for 10% degradation criterion
6. Transition Time	Passed 100 krad (Si)

### II. TOTAL IONIZING DOSE (TID) TESTING

The present testing is designed on the base of an extensive database (see, for example, TID data of antifuse-based FPGA in <http://www.klabs.org/>) accumulated from the TID testing of many generations of antifuse-based FPGAs. One distinctive quality about this testing is the bench measurement of electrical parameters. Compared to an automatic-tester measurement, the bench measurement provides lower noise, better accuracy and more flexibility. The bench measurement samples pins for some measurements (e.g. threshold voltage measurement). However, since the tolerance is determined by the most degraded parameter, which is  $I_{CC}$  or propagation delay, sampling the pins for measuring non-critical parameters is appropriate.

#### A. Device Under Test (DUT) and Irradiation Parameters

Table 1 lists the DUT and irradiation parameters. During irradiation each input or output is grounded through a 1-M ohm resistor; during annealing each input or output is grounded through a 1-k ohm resistor. Appendix A contains the schematics of the bias circuit.

Table 1 DUT and Irradiation Parameters

Part Number	RT54SX72S
Package	CQFP256
Foundry	United Microelectronics Corp.
Technology	0.25 $\mu$ m CMOS
DUT Design	TDSX72CQFP256_2Strings
Die Lot Number	DOY311-003
Quantity Tested	4
Serial Number	37467, 37468, 37471, 37473
Radiation Facility	Defense Microelectronics Activity
Radiation Source	Co-60
Dose Rate	1 krad (Si)/min ( $\pm 5\%$ )
Irradiation Temperature	Room
Irradiation and Measurement Bias ( $V_{CCI}/V_{CCA}$ )	Static at 5.0 V/2.5 V

## B. Test Method




Figure 1 Parametric test flow chart

The test method generally follows the guidelines in the military standard TM1019. Figure 1 is the flow chart showing the steps for parametric tests, irradiation, and post-irradiation annealing.

The accelerated aging, or rebound test mentioned in TM1019 is unnecessary because there is no adverse time dependent effect (TDE) in products manufactured by sub-micron CMOS technology. To prove this point, test data using a high dose rate (1 krad (Si)/min) are compared with test data using a low dose rate (1 krad (Si)/hr) for devices manufactured by several generations of sub-micron CMOS technologies. Since the results always show the low-dose-rate degradation less than the high-dose-rate degradation, the elevated rebound annealing would artificially improve the electrical parameters. Therefore, only room temperature annealing is performed in this report. DUTs are biased annealed for 90 days after the 100-krad (Si) irradiations.

## C. Design and Parametric Measurements

DUTs use a high utilization generic design (TDSX32CQ256\_2Strings) to test total dose effects in typical space applications. Appendix B contains the schematics illustrating the logic design.

Table 2 lists each electrical parameter and the corresponding logic design. The functionality is measured on the output pins (O\_AND3 and O\_AND4) of two combinational buffer-strings with 1400 buffers each and output pins (O\_OR4 and O\_NAND4) of a shift register with 1536 bits.  $I_{CC}$  is measured on the power supply of the logic-array ( $I_{CCA}$ ) and I/O ( $I_{CCI}$ ) respectively. The input logic thresholds ( $V_{TIL}/V_{IH}$ ) and output-drive voltages ( $V_{OL}/V_{OH}$ ) are measured on a combinational net, the input pin DA to the output pin QA0. The propagation delays are measured on the O\_AND4 output of one buffer string. The delay is defined as the time delay from the time of triggering edge at the CLOCK input to the time of switching state at the output O\_AND4. Both the low-to-high and high-to-low output transitions are measured; the propagation delay is defined as the average of these two transitions. The transition characteristics, measured on the output O\_AND4, are displayed as oscilloscope snapshots of the rising and falling edge during logic transitions.

Table 2 Logic Design for Parametric Measurements

Parameters	Logic Design
1. Functionality	All key architectural functions (pins O_AND3, O_AND4, O_OR3, O_OR4, and O_NAND4)
2. $I_{CC}$ ( $I_{CCA}/I_{CCI}$ )	DUT power supply
3. Input Threshold ( $V_{TIL}/V_{IH}$ )	Input buffer (pin DA to QA0)
4. Output Drive ( $V_{OL}/V_{OH}$ )	Output buffer (pin DA to QA0)
5. Propagation Delay	String of buffers (pin LOADIN to O_AND4)
6. Transition Characteristic	D flip-flop output (O_AND4)

### III. TEST RESULTS

#### A. Functionality

Every DUT passes the pre-irradiation, post-irradiation, and post-annealing functional tests.

#### B. Power Supply Current ( $I_{CCA}$ and $I_{CCI}$ )

Since the pre-irradiation  $I_{CCA}$  and  $I_{CCI}$  of every DUT are below 1 mA, the in-flux  $I_{CC}$ -plots of Figure 2 to Figure 5 basically show the radiation-induced leakage current. The room temperature annealing effect on  $I_{CC}$  is shown by Table 3, where the post-annealing data compares with the post-irradiation data.

Table 3. Post Irradiation and Post-Annealing  $I_{CC}$

DUT	$I_{CCA}$ (mA)		$I_{CCI}$ (mA)	
	Post-rad	Post-ann	Post-rad	Post-ann
37467	318	97	236	66
37468	258	94	186	40
37471	266	101	181	40
37473	282	108	207	47

An empirical equation is used to extract the total dose tolerance. The critical total dose ( $\gamma_{critical}$ ) for a 10-year mission to induce  $I_{CC}$  to 25 mA is obtained from the equation:

$$I_{CCA}(\gamma_{critical}) \times 0.32 + I_{CCI}(\gamma_{critical}) \times 0.29 = 25mA$$

Where  $I_{CCA}(\gamma)$  and  $I_{CCI}(\gamma)$  are in-flux currents when total dose equals to  $\gamma$ . Using the-worst-case in-flux currents degradation, which is DUT 37467 (Figure 2), the tolerance ( $\gamma_{critical}$ ) is obtained as approximately 62.6 krad (Si). This equation produces a conservative tolerance because the process of a high-dose-rate irradiation plus annealing produces an  $I_{CC}$  higher than the  $I_{CC}$  produced by a consistent low-dose-rate irradiation process.




Figure 2 DUT 37467 in-flux I<sub>CCA</sub> and I<sub>CCI</sub>




Figure 3 DUT 37468 in-flux I<sub>CCA</sub> and I<sub>CCI</sub>



Figure 4 DUT 37471 in-flux  $I_{CCA}$  and  $I_{CCI}$



Figure 5 DUT 37473 in-flux  $I_{CCA}$  and  $I_{CCI}$

### C. Input Logic Threshold ( $V_{IL}/V_{IH}$ )

Table 4 lists the pre-irradiation and post-annealing input logic threshold. All data are within the spec limits.

Table 4 Pre-Irradiation and Post-Annealing Input Thresholds

DUT	Pre-Irradiation		Post-Annealing	
	$V_{IL}$ (V)	$V_{IH}$ (V)	$V_{IL}$ (V)	$V_{IH}$ (V)
37467	1.31	1.45	1.27	1.52
37468	1.32	1.46	1.27	1.51
37471	1.32	1.47	1.33	1.49
37473	1.31	1.45	1.23	1.47

### D. Output-Drive Voltage ( $V_{OL}/V_{OH}$ )

The pre-irradiation and post-annealing  $V_{OL}/V_{OH}$  are listed in Tables 5 and 6. The post-annealing data are within the spec limits; in each case, the post-annealing number varies minutely with respect to the pre-irradiation number.

Table 5 Pre-Irradiation and Post-Annealing  $V_{OL}$  (V) at Various Sinking Current

DUT	1 mA		12 mA		20 mA		50 mA		100 mA	
	Pre-rad	Pos-an								
37467	0.009	0.009	0.101	0.103	0.169	0.171	0.427	0.430	0.878	0.884
37468	0.009	0.009	0.101	0.103	0.169	0.171	0.426	0.430	0.876	0.887
37471	0.009	0.009	0.103	0.104	0.172	0.173	0.433	0.436	0.890	0.896
37473	0.009	0.009	0.102	0.104	0.171	0.173	0.431	0.436	0.885	0.897

Table 6 Pre-Irradiation and Post-Annealing  $V_{OH}$  (V) at Various Sourcing Current

DUT	1 mA		8 mA		20 mA		50 mA		100 mA	
	Pre-rad	Pos-an								
37467	4.99	4.98	4.87	4.86	4.68	4.64	4.15	4.05	3.02	2.78
37468	4.99	4.98	4.88	4.86	4.68	4.65	4.16	4.08	3.09	2.85
37471	4.99	4.98	4.88	4.86	4.68	4.65	4.16	4.08	3.07	2.86
37473	4.99	4.98	4.87	4.86	4.67	4.66	4.13	4.09	3.00	2.90

### E. Propagation Delay

Tables 7 and 8 list the pre-irradiation and post-annealing propagation delays, and also the radiation-induced degradations in percentage. DUT 37473 has the worst degradation of 10.08%.

Table 7 Radiation-Induced Propagation Delay Degradations

DUT	Pre-Irradiation	Post-Annealing	Degradation
37467	1467.4	1557.8	6.16%
37468	1432.0	1466.2	2.39%
37471	1441.4	1482.1	2.83%
37473	1431.2	1575.4	10.08%

#### F. Transition Time

Figures 6 to 13 show the pre-irradiation and post-annealing transition edges. In each case, the radiation-induced transition time degradation is not significant. Notice that in these Figures, the pre-irradiation time scale is different from the post-annealing time scale.




Figure 6(a) DUT 37467 pre-irradiation rising edge, abscissa scale is 2 V/div and ordinate scale is 5 ns/div.




Figure 6(b) DUT 37467 post-annealing rising edge, abscissa scale is 2 V/div and ordinate scale is 2 ns/div.




Figure 7(a) DUT 37468 pre-irradiation rising edge, abscissa scale is 2 V/div and ordinate scale is 5 ns/div.




Figure 7(b) DUT 37468 post-annealing rising edge, abscissa scale is 2 V/div and ordinate scale is 2 ns/div.




Figure 8(a) DUT 37471 pre-irradiation rising edge, abscissa scale is 2 V/div and ordinate scale is 5 ns/div.




Figure 8(b) DUT 37471 post-annealing rising edge, abscissa scale is 2 V/div and ordinate scale is 2 ns/div.




Figure 9(a) DUT 37473 pre-irradiation rising edge, abscissa scale is 2 V/div and ordinate scale is 5 ns/div.




Figure 9(b) DUT 37473 post-annealing rising edge, abscissa scale is 2 V/div and ordinate scale is 2 ns/div.




Figure 10(a) DUT 37467 pre-irradiation falling edge, abscissa scale is 2 V/div and ordinate scale is 5 ns/div.




Figure 10(b) DUT 37467 post-annealing falling edge, abscissa scale is 2 V/div and ordinate scale is 2 ns/div.




Figure 11(a) DUT 37468 pre-irradiation falling edge, abscissa scale is 2 V/div and ordinate scale is 5 ns/div.




Figure 11(b) DUT 37468 post-annealing falling edge, abscissa scale is 2 V/div and ordinate scale is 2 ns/div.




Figure 12(a) DUT 37471 pre-irradiation falling edge, abscissa scale is 2 V/div and ordinate scale is 5 ns/div.




Figure 12(b) DUT 37471 post-annealing falling edge, abscissa scale is 2 V/div and ordinate scale is 2 ns/div.




Figure 13(a) DUT 37473 pre-irradiation falling edge, abscissa scale is 2 V/div and ordinate scale is 5 ns/div.






Figure 13(b) DUT 37473 post-annealing falling edge, abscissa scale is 2 V/div and ordinate scale is 2 ns/div.

## APPENDIX A DUT BIAS





## APPENDIX B DUT DESIGN SCHEMATICS

