

Synopsys[®], Inc.

700 East Middlefield Road Mountain View, CA 94043 USA

Website: www.synopsys.com

Identify® Microsemi Edition Tool Set Release Notes

Version J-2014.09M-1, November 2014

Publication Version 01

Contents

About This Release
Device Support
Installation
Platform Support
Identify Documentation
Resolved Issues
Important Issues and Workarounds

About This Release

These release notes describe features and enhancements for the J-2014.09M-1 release of the Identify Microsemi Edition tool set. This release introduces support for the Linux operating system and synchronizes the tool set with the I-2014.03M-SP1 release of the Synplify Pro synthesis tool. The release also addresses a reported critical issue with an earlier release (STAR 9000723280).

Device Support

The J-2014.09M-1 release supports the following Microsemi device families. Device selection is specified solely in the synthesis tool and passed to the Identify instrumentor in the synthesis project file. Specifying a library in the synthesis tool that is not supported in the Identify tool set results in a "device not supported" message when attempting to launch the Identify instrumentor.


Fusion	SmartFusion	SmartFusion2
IGLOO	IGLOOe	IGLOO PLUS
IGLOO2	ProASIC	ProASIC PLUS
ProASIC3	ProASIC3E	ProASIC3L

Installation

The directory where Identify is installed is referred to as the *installDirectory*. The installation subdirectory name consists of the Identify product name and an associated version number, in the current case, Identify_J201409M-1 (for version J-2014.09M-1). This naming convention permits multiple versions to be installed in the same product directory. On Windows platforms, the start menus, desktop icons, and uninstall names have an associated version number, in the current case, Identify J-2014.09M-1. For a list of the compatible Windows-based platforms, see *Platform Support* on page 3.

Downloading the Software

The Identify software is installed directly from the downloaded exe file. Installing the software creates the Identify_J201409M-1 subdirectory in the installation directory. This directory contains the following files and subdirectories:



The contents of the files or sub-directories are as follows:

Directory	Contents
bin, linux, linux_a_64, win64	Executables for the Identify instrumentor and Identify debugger; debugger; linux and linux_a_64 are included with Linux installations, win64 is included with Windows installations.
CseJtag	Drivers
doc	User documentation
etc	Location for user-defined startup scripts; template included
lib	Program data files
share	Includes the following subdirectories: contrib – source directory for scripts executed on startup synthesis – program specific data files tutorial – the bus_demo and counter designs for the tutorials
Text Files	ASCII version of the Synopsys Software License and Maintenance Agreement

Platform Support

The Identify J-2014.09M-1 release is compatible with the following platforms and operating systems:

- Windows:
 - Windows 7 Professional or Enterprise (32/64-bit)
- Linux:
 - Red Hat Enterprise Linux 5 (32/64-bit)
 - Red Hat Enterprise Linux 6 (64-bit)
 - SUSE Linux Enterprise 10 (32/64-bit)
 - SUSE Linux Enterprise 11 (64-bit)

Synopsys FPGA Synthesis Tool Requirements

The J-2014.09M-1 release of the Identify tool set can only be used with the following Synopsys FPGA tools on the above platforms and operating systems.

Tool	Required Version
Synplify Pro synthesis tool	FPGA I-2014.03M-SP1

Machine Requirements

Machine memory requirements vary according to the size and complexity of your designs. At a minimum, 4 GBytes of RAM are generally required. Your machine's virtual memory (swap space) should be set to at least twice the capacity of the RAM.

Location of the cfg File

Windows platforms do not permit applications to write to the C:/Windows directory. Because the Identify tools must update the userprefs.cfg initialization file, this file is written to the following directory location:

C:\Users\userName\AppData\Roaming\Identify

Windows Memory Configuration

For all memory configurations, Windows uses a default virtual address space of 4 GBytes; 2 GBytes allocated to user processes (applications) and 2GBytes allocated to the operating system and kernel-mode drivers. On Windows systems that have 1 GByte or more of physical memory, the memory allocation between applications and operating system can be modified to increase the user-process memory allocation to 3 GBytes (and reduce the operating system memory allocation to 1 GByte). For the most up-to-date information for reconfiguring memory allocation on a compatible system, see *How to Set the /3GB Startup Switch in Windows* and related topics on the Microsoft TechNet (http://www.microsoft.com/technet).

Identify Documentation

The following documentation is included with the J-2014.09M-1 release of the Identify tool set:

- Identify Microsemi Edition Tool Set Release Notes (this document)
- Identify Microsemi Edition User Guide
- Identify Microsemi Edition Reference Manual
- · Identify Microsemi Edition Quick Start Guide
- Identify Microsemi Edition Quick Tutorial
- · Identify Microsemi Edition Tutorial
- Synopsys Software License and Maintenance Agreement

Accessing Documents using the Acrobat Reader

PDF documents display in Adobe Acrobat Reader. You can download the latest Acrobat Reader at no cost from Adobe's website (www.adobe.com). The PDF files provided are optimized for output to a laser printer, not for viewing online.

From within the software, you can open the PDF documents by selecting Help->Online Documents and selecting the appropriate PDF. You can also access PDF documents without running the software by going to Start->Programs->Synopsys->Identify J-2014.09M-1->Documents and selecting the desired PDF document.

Note: Do not use the View->Full Screen option when viewing documents in Acrobat Reader unless you are sure you want this full magnification. On some applications, this selection takes over the monitor and there is no apparent way to access other running tasks or windows. If you do happen to use the Full Screen option, you can use Ctrl-I to undo it.

Resolved Issues

The following issues have been resolved by the Identify J-2014.09M-1 release:

Resolved Issue: When an implementation included an edf black-box module, the Identify instrumentor would error out complaining about an undefined module.

Important Issues and Workarounds

The following issues have been identified with the Identify J-2014.09M-1 release:

Problem: When using VHDL, if the trigger signal (scalar) is of type std_logic, the value must be enclosed in single quotes in both the UI and the shell as shown in the following command:

```
watch enable -iice IICE -condition 0 /my signal {'0'}
```

Entering a scalar signal without quotes or in double quotes results in an error. Conversely, vectors must be entered without quotes as shown in the following command:

```
watch enable -iice IICE -condition 0 /my bus {1010}
```

Workaround: Make sure that all scalars are enclosed in single quotes and that vectors are entered without quotes.

Problem: The message suppression feature available with the synthesis tools cannot be used to suppress (or change the severity of) messages generated by the Identify tool set.

Workaround: Be sure to disable message suppression when using an Identify implementation.

Problem: Use of external triggers via the import trigger mechanism causes an excessive use of internal block RAM due to sampling of the trigger as well as the creation of a look-up table. The problem is most notable when the maximum of eight imported triggers is selected. A better mechanism to import triggers that uses fewer resources will be available in a future release.

Workaround: Add an extra input to the top-level RTL code and instrument the input as a trigger only.

Problem: Cross-triggering can cause Identify Debugger to crash if a trigger condition is not set for each IICE.

Workaround: Set a trigger for each IICE (even a dummy trigger).



Synopsys, Inc.

700 East Middlefield Road, Mountain View, CA 94043 USA

Copyright © 2014 Synopsys, Inc. All rights reserved. Specifications subject to change without notice. Synopsys, Identify, and Synplify Pro are registered trademarks of Synopsys, Inc. IICE is a trademark of Synopsys, Inc. All other names mentioned herein are trademarks or registered trademarks of their respective companies.