




NOTE 1: ASSEMBLE THE THERMAL_PAD(A10462-03) BETWEEN THE HEAT SINK(1_HS1) AND AOR107-B0-IG-Y(1_U1)





NOTE 2: PLEASE TAKE CARE DURING ASSEMBLY FOR JUMPER 1_J24 & 1_J25



PACTRON	
DATE: JULY 2018	
NAME: PF_VIDEO_KIT_10G_DAUGHTER_BOARD	REV: 1
FILM LAYER: SILKSCREEN_TOP	



LOAD STAND-OFF'S(970180321) AND SCREW(92000A118) IN THE MARKED LOCATIONS (2 LOCATIONS)



FILM LAYER: SILKSCREEN_BOTTOM
NAME: PF_VIDEO_KIT_10G_DAUGHTER_BOARD
REV: 1
DATE: JULY 2018
PACTRON